

Important Information

Maximum carrying capacity: 75kg (165lbs) evenly distributed over the cross bars. Please refer to your vehicle manufacturers handbook and DK Specification sheet for maximum roof loading. Always use the lower of the two figures.

Recommendations:

It is essential that all bolt connections be checked after driving a short distance when you first install your cross bars. Bolt connections should be checked again at regular intervals (probably once a week is enough, depending on road conditions, usage, loads and distances travelled). You should also check the cross bars each time they are refitted. Make sure to fasten your load securely. Please ensure that all loads are evenly distributed and that the centre of gravity is kept as low as possible.

Use only non-stretch fastening ropes or straps.

Caution: The handling characteristics of the vehicle changes when you transport a load on the roof. For safety reasons we recommend you exercise extreme care when transporting wind-resistant loads. Special consideration must be taken into account when cornering and braking.

Please remove cross bars when putting vehicle through an automatic car wash.

Load Ratings:

Maximum permissible load is 75kg (165lbs) for two cross bars including the weight of the cross bars, 5kg (11lbs). When cross bars are to be used in off-road conditions, please build a safety factor of 1.5 into this load limit for off-road use, two cross bars = **50kg 110lbs**). Although the cross bars are tested and approved to AS1235-2000, Off road conditions can be much more rigorous. However, increasing the number of cross bars does not increase the vehicles maximum permissible roof loading.

Note for Dealers and Fitters:

It is your responsibility to ensure instructions are given to the end user or client.

Rhino-Rack 3 Pike Street, Rydalmere, NSW 2116, Australia. (Ph) (02) 9638 4744 (Fax) (02) 9638 4822

Document No: 2501 Prepared By: Craig Jones Authorised By: Gary England


Issue No: 02 Issue Date: 19/04/2010

These instructions remain the property of Rhino-Rack Australia Pty. Ltd. and may not be used or changed for any other purpose than intended.

Rhino 2500 Series - Two Bar Aero System

Carrying Capacity: Refer to DK specification sheet for maximum carrying capacity of your particular vehicle. Parts List Qty **Component Name** Part No. Item Rubber Buffer Strip 2 R011 1 1 2 A155 2 Aero Cross Bar 2 N047 M8 Pivot Nut 4 3 3 M8 x 50mm Security Bolt 4 B154 4 4 5 End Cap 4 M153 5 Bar Measurement Strip 4 M332 6 6 7 4 M310 Leg 7 8 Leg Cover Plate 4 M324 8 9 M6 Nut 4 N057 9 4 W003 M6 Flat Washer 10 10 0 M6 Spring Washer 4 W004 11 ത 11 B137 12 M6 x 25mm Security Screw 4 12 4 13 Front Cover M312 2 M314 13 14 Front Cover Key 15 Foot Plate 4 M311 14 16 Security Allen Key 1 SecKey-L 15 17 Leg Location Decals 4 S365 16 18 Arrow Positioning Decals 4 S364 2501 19 **Fitting Instruction** 1 **Tools Required:** 17 Security Allen key, provided in kit. Tape measure. Pad & clamp kit Scissors. available separately |���� -18 Rubber mallet.

NOTE : Refer to the DK kit specification sheet for correct placement (*Front & Rear, Left & Right*) of the foot plate, rubber pad and metal strap. Also refer for sizes to cut the bar measurement strips.



Attach hardware:

Locate the M6 x 25mm security screw, spring washer and flat washer through top the leg and fasten to the M6 nut. Do not tighten at this stage.

