



## AMERICAN CAR CRAFT INSTRUCTIONS

### C5 Corvette Taillight Trim Rings Polished Part #032053



#### PARTS INCLUDED:

4-Stainless Taillight Grilles

8-2" Polished Stainless Truss Head Replacement Screws

**Liner Information:** Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and or possible scratches during installation.

1. Remove all eight factory screws from the taillights. **NOTE:** These screws will not be reused.
2. Carefully place each taillight cover into position. Do this slowly so that you do not scratch your paint. (If you feel more comfortable you can tape the painted area around your taillights using masking tape before installing your new stainless covers). The covers will come to you contoured to the shape of the factory lens however take a few minutes to further shape the covers by hand just to make sure you have a nice end result.  
**NOTE:** The lamps tend to move, so if you use something smaller in diameter then the screws like a "small" Phillips screwdriver to align everything and then hold it in place prior to installing the new screws, it will make getting the screws started properly much easier. Another note to keep in mind is that the holes in the factory lens are a little offset so it is possible to put the new covers in upside down. Take a minute to check this out so as to make sure your covers are being set right side up. Another note to keep in mind is that the lens opening in the rear valance is slightly smaller than the lens itself so in order to place the new covers over the lens you will need to sort of tuck the top of the cover up into the opening as you bring the bottom area into position.
3. Once your cover is in position, install the replacement polished screws (provided) and fasten securely being careful not to over tighten.