



AMERICAN CAR CRAFT INSTRUCTIONS

C6 Rear View Mirror Trim “Corvette” Style Auto Dim Part #041034



PARTS INCLUDED:

1-Stainless Mirror Trim Rings

This all new stainless trim ring accessories is an American Car Craft original idea that will add that cool little something to your car mirrors that would otherwise just be a plain OEM mirror.

1. Thoroughly clean the mirrors glass and perimeter with alcohol to remove any dust /dirt and wax.
2. Before you permanently attach the trim ring, set it onto the mirror to get an idea of just how it will set in place and also to get a look at the overall shape. Although it should not be necessary you may need to adjust the perimeter shape so that it matches the mirrors edge perfectly. The stainless is very thin and will allow you to do any adjustment by hand very easily. **TECH TIP:** Should any adjustments be necessary it would be best to set the trim ring on a totally flat surface such as a Formica counter top or piece of glass.

This will help to prevent the trim ring from warping out of shape and will keep the ring to remain totally flat.

3. After you have got a good idea how the ring will sit, slowly remove the release liner from the back of the trim ring and then carefully set the ring in place pressing firmly along the entire perimeter to set the ring. Pressing firmly along the edge is very important to achieve a nice long lasting bond.

Thank you and enjoy your purchase!