

ADDICTIVE DESERT DESIGNS

2010 – 2014 FORD RAPTOR RACE SERIES R SIDE STEPS INSTALLATION INSTRUCTIONS

PREPARATION STEPS

1. Disconnect the negative terminal on the battery. With the vehicle on level ground and the emergency brake set.
2. You will need the following tools:
 - a. 13MM Socket and Ratchet
 - b. 3/16 Allen Wrench
3. Hardware required:
 - a. 16 – 13mm Factory Bolts will be re-used for the installation
4. Hardware provided:
 - a. 16 – 5/16 x 18 Button Head Bolts
 - b. 16 – 5/16 x 18 Nut Clips
 - c. 16 – 5/16 Washers


**** A.D.D. provides hardware in case there is no factory hardware available. You may use either set of hardware to install your new side steps.**

INSTALLATION INSTRUCTIONS

1. Remove factory Side Steps by removing the 16 – 13mm bolts (8 per side). Keep the Bolts as they will be reused. Use the A.D.D hardware if no factory side step hardware available.



2. Attach the Side Step back into the factory location, using the 8 – Bolts per side



3. Step back and enjoy your new A.D.D. Race Series R Side Steps.



4. Check, and re-tighten if needed, all mounting bolts after 100 miles and periodically thereafter.

Looking for dependable off-road bumpers? Rely on Addictive Desert Designs for quality and long-lasting products.