



Tools Needed:  
4 Splicer's



Step 1: Locate the two clips located at the top of the headlight.



Step 2: Remove the two clips which hold the headlight to the frame.



Step 3: Pull the headlight assembly straight out of the housing.



Step 4: Unplug the high and low beam harness from the bulbs.



Step 5: Remove the turn signal socket from the headlight.



Step 6: Take the anzo headlight, splice in the red wire to blue and red wire to black to power up the halo's



Step 7: Plug the headlight harness to the ANZO headlight



Make sure all functions work properly before driving.