



Tools needed: Phillips
screwdriver 10mm socket.



Step 1: Remove the two phillips
screw holding in the rubber
guard.



Step 2: Remove the two 10mm
bolts holding in the headlight.



Step 3: Remove the 10mm
located under the corner bulb on
the headlight.



Step 4: Pull out the headlight
from the vehicle.



Step 5: Twist off the corner light
bulb



Step 7: Twist off the headlight
bulb.



Step 8: Remove the headlight
bulb from the wire harness.



Step 9: Remove the corner light
bulb.



Step 10: Pull out the new
headlight from the box.



Step 11: Plug in the corner light
bulb wire harness into the new
headlight.



Step 12: Plug in the headlight wire harness into the new headlight.



Step 13: Test all functions for proper installation before driving.

