



Read complete instructions before installation! Improper installation may void warranty



Tools needed 10mm Socket and ratchet Phillips Screwdriver



Pull the light staright out.



Plug the 3 sockets into the back of the new light.



Remove the two 10mm bolts from the top of the light. Also remove the phillips push pin from the rubber flap.



Remove the 3 light sockets by twisting and pulling outward .



Install your new light. Be sure to line everything up correctly. Replace your stock bolts and push pin.



Pull the flap to one side and remove the 10mm bolt holding the housing in place.



The small 194 bulb will need to be removed from the socket.



Check all functions of the light before driving on the highway.

Anzo Lights Custom Headlights