

Rampage Products

Frameless Trail Top (1095xx, 1096xx and 1097xx)

Installation Tip Addendum

The Frameless Trail Top is an innovative top designed to be the only top a person will ever need. Due to its design however, installation can be tricky at times. New fabric, fresh seams and cold weather all play a part in the top's installation.

Occasionally during install as per the instructions, consumers may think that their back window is not cut in the right shape and/or they are unable to connect both side zippers. The back window is designed to have a taper of approximately 3" top to bottom. The back window may appear to not be built correctly, but is in fact correct for the vehicle. Reference Figure A for a visual of what the consumer could be concerned about. Please review these alternate installation instructions and save this file for use when working with consumers.



- When installing the top, make sure the material is warm to the touch
- Get the main skin installed per the instructions.
- Put in your side panel, get the main skin/side panel zipper started about 6 inches.
- Fit the plastic strip into the door surround - But do not install the plastic strip into the body yet.
- Repeat on the opposite side.
- Put back window into place, hooking up the three straps across the top.
- Hook up the back window/side window zipper, run it down 6" or so.
- Hook up zipper on opposite side of back window, run it down about 6".
- Not having the plastic seal in the body will give you more movement to hook up the back window zippers.
- Install the plastic strip into the body on both sides. Run all 4 zippers to their ends.

Rampage Products
www.rampageproducts.com
Phone: 951-277-4949
Fax: 951-277-4949
eMail: info@rampageproducts.net