



Cipa Stock No.56000or56100

'95-' 98Chevrolet/GMC CK,Suburban,Yukon,or Tahoe Mirror

INSTALLATION INSTUCTIONS

(Replaces manual or electric models OEN mirror)

1. Using the Trim Panel Remover Tool(supplied),carefully remove the mirror access panel at the upper front of the interior door panel.This is attached to the door with a single retainer that is located near the top of fhe panel.Gently pull the panel out at the top until clip clears the sheet metal and then lift panel out.
- 2.Remove the noise insulator foam that is covering the mirror retaining nuts.Save it for re installation.
3. Carefully disconnect the power harness from the vehicle(if applicable on your model)
4. It is helpful to have someone holding up the mirror you are removing at this point. Using the 10mm wrench and socket,remove the three attaching nuts.(NOTE:It is best to cover the opening below the mirrors attaching nuts(w/a rag or something like that) to prevent the nuts from falling down inside the door when removed.
5. Place your new CIPA mirror into position and attach the three nuts supplied. Tighten to 53 inch pounds (6N.m), or snug as possible.
6. Replace the noise insulator foam piece.
- 7.Reattach the access cover on the door.

Tools Needed

- 10mm box end wrench.
- 10mm deep socket and ratchet wrench.
- Trim Panel Remover Tool (supplied)