



## **RADIATOR MOUNTING KIT P/N C4925**

Designed to mount the popular Volkswagen Scirocco style radiator or any aftermarket aluminum radiator with the VW Scirocco mounting pattern.

### **Parts List**

- (2) Mounting Bung
- (2) 1/4"-20 x 1 1/4" Bolt
- (2) 1/4"-20 Locknut
- (2) Radiator Mounts

### **INSTALLATION INSTRUCTIONS**

1. Bolt the Mounting Brackets to the radiator.
2. Using the radiator as a fixture to locate the Mounting Bungs on the chassis, hold the radiator in position on the chassis or cross member.
3. Mark the chassis where the Mounting Bungs are to mount.
4. Tack weld the weld Mounting Bungs in place.
5. Slip the Radiator/Bracket assembly into the Mounting Bungs.
6. Check the radiator position for height and check the clearance between the radiator and engine accessories.
7. After the radiator has been properly positioned, remove the radiator and finish weld the Mounting Bungs to the chassis.
8. Re-install the radiator assembly into the Mounting Bungs on the chassis.
9. Mark the Mounting Bungs for the Quick Pins. Drill a 1/4" diameter hole through the Mounting Bungs and radiator uprights.
10. De-burr the holes and re-install radiator assembly.
11. Install 1/4" Bolt and Nut.