

INSTALLATION GUIDE

Chevy Silverado (2016+)





Included Hardware:

- (6) 1/2" Bolts
- (6) 1/2" Nylon Locking Nuts
- (12) 1/2" Washers
- (2) 3/8" Bolts
- (2) 3/8" Locking Nuts
- (4) 3/8" Washers
- License Plate Light Kit

Tools:

3/4" wrench and socket

Skill Level:

2/5 stars (Professional install recommended)

License Plate Removal

Remove license plate from rear bumper



Trailer Component Receiver Removal

Unplug wiring from rear and pull out of bumper



Bolt Removal

Unscrew the two bolts behind receiver component as shown in the picture



Remove License Plate Stock Lights

Remove the stock light wiring as shown



Stock Bumper Removal

Remove stock bolts underneath each corner of stock bumper



Plastic Tread Plate Removal

Pry and pull away the plastic tread from rear bumper as shown and remove bolts from underneath



Underside Stock Bumper Bolts

Remove stock bolts underneath stock bumper as shown in the photo



Stock Bumper Removal

Pull and remove stock bumper from frame



Stock Reinforcement Bracket Removal

Remove the three upper and one lower bolts holding the stock reinforcement bracket



New Reinforcement Bracket Install

Using existing stock bolts and bolts provided, hand tighten the bracket into place but keep loose for rear bumper adjustment.



New Reinforcement Bracket Install (Continued)

Use existing bolt and 3/8" bolt shown here



New Reinforcement Bracket Install (Continued)

Use 1/2" bolt as shown in photo to attach underneath frame reinforcement bracket.



Bumper Fitting & Alignment

Place the bumper onto the frame and check for centering and alignment. Once satisfied, tighten down reinforcement bracket bolts. Enjoy!

