

PART# TOY-1821

(3) #8 "U" NUTS

(3) #8 X 5/8 HEX SCREWS



2010-2011 TOYOTA PRIUS LOWER GRILLE INSTALL PART# TOY-1821



Open the front hood.



Remove the plastic clips that secure the plastic under hood trim panel.



Remove plastic trim panel.



Remove the bolts that secure the top section of the bumper cover to the vehicle.



Remove the plastic clips along the top side of the bumper cover.



Remove the screw located in the front fender well there is one screw on each side.



Remove the plastic clip located in the front fender well there is one on each side.



Remove the plastic push clips and bolts located on the front underside of the bumper cover.



Pull the top portion of the bumper cover forward in order to unclip from vehicle.



Pull the right & left side of the bumper cover in order to unclip cover from vehicle.



Now remove bumper cover from vehicle. Make sure when removing cover to unclip lamp plugs.



Place the GrillCraft grille inserts into the lower openings as shown. Inserts fit over the factory grille. Cutting factory grille bars is optional



TOY-1821



While holding insert in place mark mounting tab center hole location using a sharp scribe.



Using 3/16 drill bit drill holes for the mounting screws.



OPTIONAL As a option you can cut the factory lower grille bars out as shown.



Place the supplied "U" nuts onto the grille mounting tabs as shown.



Fasten the lower grille insert screws from the back side as shown.



Reinstall bumper cover to vehicle.



In order to use the factory license plate holder. You will need to cut the lower portion as shown in the photo this will allow the plate holder to clear the newly installed grille.



FINISHED!