

Congratulations on your purchase of a high quality PUTCO product.

Please read all instructions before beginning installation and be sure to check to see that all parts and hardware are included.

Parts List		
Description		Qty
Grille Insert		1
Upper Grille Surround		1
Lower Grille Surround		1
Front Bumper		1
Fog Light Surrounds		2
Front Tow Hook Cover		1
Lower Grille Insert		1
Chrome Vent Surrounds		2
Chrome Center Chin Spoiler		1
Side Chin Spoilers		2
Front Bumper Side Vents		2
Rear Bumper		1
Rear Bumper Insert		1
Rear Bumper Chrome Accent		1
Rear Bumper Side Trim Pieces		2
Rear Bumper Tow Hook Cover		1
Side Skirts		2
Door Sills		2

Tools Needed for Installation
Wire Cutters
Electrical Crimping Tool
Wire Strippers
T27, T20 Torx Sockets
Non-Abrasive Towel
10mm Socket
Ratchet



Step 1: Verify kit contents.

Step 2: Take out factory grille by removing 4 retaining clips located on the top of the part.

Step 3: Remove the front fender liners; there are 6 clips and 2 Torx fasteners holding each side in place.

Step 4: Remove the front fender flares by pinching the clips on the inside of the fender.

Step 5: Disconnect the wiring located in the bumper; this includes the air temperature sensor, the fog and accessory lighting.

Step 6: Take out the two T20 Torx screws and three clips underneath the front bumper. Unscrew the four other Torx screws holding the bumper in place; they are located on the upper portion of each side of the bumper and in the middle. Then remove the front bumper.



Step 7: Remove the screws and clips located below the doors that hold the side skirts in place. Remove the side skirts.

(NOTE: The side skirts will need to substantial force to loosen the upper clips.)

Step 8: Remove rear fender liners. Each side is held in place with four clips and two screws.

Step 9: Locate and remove two 8mm bolts located underneath the middle of the rear bumper.

Step 10: Release reverse light connectors and remove rear bumper.

(NOTE: There is a hidden clip located in the middle of the bumper that may need extra force to release.)



Step 11: Using the OEM fog lights; assemble the Putco front bumper with the front spoiler pieces and bumper inserts.

Step 12: Install the Putco front bumper on the vehicle.



Step 13: If your body kit came with the optional Daytime Running Lights; use the enclosed Scotchloks to attach the Putco Daytime Running light wires (Red(+) and Black(-)) to the OEM White(+) and Brown(-) that provide power to the Fog/Accessory lights. The Putco blue wire can be connected to provide dimming capabilities.

Step 14: Use the enclosed clips and install the Putco side skirts, then apply the metal door sill.

Step 15: Attach trim pieces to the Putco rear bumper and install bumper on vehicle.

Step 16: Connect the Putco reverse light wires to the OEM reverse light wires using Scotchloks. Connect Putco Red(+) to OEM Blue(+) and Putco Black(-) to OEM Brown(-).

Step 17: Reinstall rear fender liners and fender flares.

Step 18: Remove factory grille surround that is attached to the hood. Reuse the connectors from the factory surround in the Putco part when installing on vehicle.

Note: If your lights do not turn on verify the connection between the Factory and Putco wiring is secured properly.
