



SPYDER

INSTALLATION GUIDE: PRO-YD-ME00-HL(ALL COLORS)

Tools Required

10mm Socket wrench/ratchet

Please Note

If you are unfamiliar with the installation processes, professional installation is highly recommended.



1) Open your hood to reveal the headlight assembly. In order to unmount the headlight you will need to remove (3) 10mm bolts that hold the headlight in place. The locations are indicated by the red arrows.



2) Once the bolts have been removed, you will need to remove the headlight harness connected to the OEM headlamp, shown here. Once the harness is disconnected, pry the light assembly free.



3) Once the assembly is removed and the harness is disconnected, attach the new Spyder harness to the OEM harness as shown in figure (2), remount the headlight, and reinsert the mounting bolts that were removed in figure (1).



4) Lastly, test the new headlight assembly. Low beam and high beam will only come on individually and will not stay on together. Above is for reference only. Halo LED's require additional wiring;