



Recommended filter cleaning interval every 3000 miles

Part# **Secret Weapon Intake 307-184**

US Patent# **US 7,263,961B2**

Application: **2009 Pontiac G8 GT V8**

**Parts List: 1 x 4" Weapon*R Air Filter / 1 x Weapon*R Aluminum [Air Intake](#) Tube / 2 x 3.5"-4" Silicon Coupler
1 x 3.5"- 3.5" Silicon Couplers / 1 X 10MM / 6 x Hose Clamps /**

- 1 Loosen hose clamps securing OEM intake hose.
- 2 Remove OEM intake hose.
- 3 Remove nut securing OEM air box, save for later steps . Disconnect rubber PCV hose from side of air box.
- 4 Pull air box upwards to remove. Remove MAF and Disconnect and set aside
- 5 Install 4" side of 3.5"-4" Weapon*R coupler over throttle body and secure with supplied clamp.
- 6 Insert Weapon*R intake pipe into 3.5" side of the coupler on the throttle body
- 7 Install 3.5"-3.5" coupler onto end of WR pipe and secure with clamp
- 8 Reinstall the MAF into the 3.5" side of the WR coupler and clamp down
- 9 Install 3.5"-4" Coupler onto MAF, Clamping down 3.5" side to MAF
- 10 Secure loosely with supplied clamps. Connect OEM PCV hose to Weapon*R intake pipe.
- 11 Insert Weapon*R filter into 4" end of 3.5"-4" coupler. Secure with supplied clamp.

- 12 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances. Inspect engine compartment for loose tools and or loose clamps and bolts to be properly tightened. Start engine and let idle for 10 minutes before Revving the engine, to allow the ECU to re-map new Air / Fuel Ratio curves to increased air intake to the engine. Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable) Perform a final inspection before driving vehicle.

Installation of your New Weapon*R Performance Intake System is completed, we hope you enjoy our performance products.

