



Dodge Charger 2015-present Int. Knob Kit

ABD-3114XXX

INSTRUCTIONS

Tools Needed:

- Rag
- Channel locks
- Flat head screw driver

Take care not to scratch your new knob covers during this installation. While sitting in the car, familiarize yourself with the 11 knobs, buttons, pins or bezels which will get a new cover, pin or bezel. These include:

- 1 fan control knobs located in the center of the dash below the two radio tuner knobs this is also the bigger of the three covers - These covers are installed by pressing onto the knob until completely seated.
- 2 radio tuner knobs located in the center of the dash above the fan control - These covers are installed by pressing onto the knob until completely seated.
- 4 door lock bezels these are located on each door - **These bezels will need to be removed first before removing the door lock pin. Carefully slide a flat head screw driver under bezel (careful not to damage material surrounding bezel) gently pry lifting plastic bezel out of door. Leave new bezel to the side and move to next step. All four bezels are universal for the front and the back.**
- 4 door lock pins located on each door - **Once your previous door lock bezel is removed you will need to remove the factory door lock pin. To remove the door lock pin place a rag over the pin and grab the pin with your channel locks, you will need to grab tightly so you can un-screw the pin. (This step can damage your factory pin). Once Pin has been un-screwed take your new pin and thread until it bottoms out. Take your new bezel and press down over the pin into the door. PLEASE NOTE THERE IS A FRONT PAIR AND REAR PAIR TO THE PINS. THE FRONT SET HAS THE O-RING CLOSER TO THE TOP OR DOMED PART OF THE PIN. WHEREAS, THE REAR SET IS CLOSER TO THE BOTTOM OF THE PART.** Your installation should be complete, now enjoy!