



GENERAL INSTALLATION INSTRUCTIONS  
Universal Clear LED Replacement Taillight  
Part # 861037

**Installation Notes:**

1. Please read the special instructions section at the bottom of the instructions to determine the correct parts needed for your installation.
2. Please read all instructions before installing.
3. The following procedure describes a generic (typical) installation.
4. Prior to installation check all parts and inspect for damage and/or cracks
5. Lighting laws vary depending on the jurisdiction, check your local laws before installation.
6. Consult your local mechanic or technician if uncertain of wiring or installation.

**Installation:**

1. Remove the stock light from the vehicle
2. Take the Anzo light out of the package and remove the front cover
3. Set the stock light and the Anzo light next to each other face down
4. With your screw driver punch out the correct mounting holes on the back of the Anzo light
5. Flip the Anzo light back over and pull the center portion up and out
6. Insert the supplied mounting bolts into the holes you punched out
7. Mount the light onto the vehicle
8. Replace the center section back in the light housing and bolt the cover in place

**Wiring:**

1. Splice the red wire into the reverse wire (not required on some vehicles)
2. Splice the brown wire into the driving/running light wire
3. Splice the yellow wire into the brake/turn signal wire.

Check the light for proper function after installation.



*AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.*



GENERAL INSTALLATION INSTRUCTIONS  
Universal Clear LED Replacement Taillight  
Part # 861037

**Special Instructions:**

For 87-95 Jeep Wrangler you will need to upgrade your turn signal flasher to a LL552 flasher in order for the lights to work properly. This flasher is available at any local auto part store.



Your flasher is located under the steering column on the firewall.

For 97-2006 Jeep Wrangler use the supplied resistor.



Connect one side of the resistor to the plate  
Inside the taillight assembly.

The other end of the resistor will get  
spliced in with the brake/turn signal  
wire.

Be sure to test all functions of the  
light before operating your vehicle on  
the highway.

*AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.*