

UNIVERSAL FENDERBAG

Mounting and Use Instructions

If you intend to carry heavier loads or your bike is not equipped with a rear frame loop, it will be necessary for you to bolt the Fenderbag to your rear fender.

To secure your bag:

1. You will need four bolts, four nuts and eight washers. (They are not included in this package) We suggest that you use 6mm or 1/4 in. bolts approximately 14 in. long, a self-locking nut or Loctite and large O. D. fender washers, one inside the bag and one under the fender.
2. Drill holes in your fender as far apart as the fender and bag will allow
3. Using a soldering iron or punch, make holes in the bottom of the bag to match the holes in your fender.
4. Now boll the bag down. making sure that the excess length of bolt does not interfere with tire clearance. For some applications it is best to put the head of the bolt on the tire side of the fender.
5. Trim the excess length of bolt as necessary.

Note: If you have any problem you cannot solve, please call us. We will be more than happy to advise you.

Cleaning: Open all zippers. remove all inserts and hardware, set machine on light or regular cycle, use cold or warm water and a mild detergent. Hang dry. Do not dry clean or put in dryer. Touch-up cleaning may be done with spray cleaners or detergent and water.