



## INSTALLATION INSTRUCTIONS For Part #'s:

**10900, 10950**

**NOTE:**

BEFORE ATTACHING **MIRROR**, WE RECOMMEND THAT YOU CLEAN VEHICLE MIRROR. YOU MAY ALSO WISH TO APPLY A THIN COAT OF WAX.

REMOVE CUSTOM TOWING MIRROR BEFORE ENTERING AUTOMATIC CARWASHES. USE EXTRA CAUTION WHEN APPROACHING TIGHT SPACES, SUCH AS ATM TERMINALS, AND OTHER DRIVE-THROUGH SERVICES.

