

Fab Four's

MADE IN THE USA



WINCH BUMPERS & VEHICLE ACCESSORIES
QUALITY, DELIVERED ON TIME!



BLACK STEEL

ELITE



BLACK STEEL





FS11-A2551-1 // 11-15 FORD SD F250-F350 BUMPER W/ NO GUARD



CH14-A3052-1 // 15-16 CHEVY HD 2500-3500 BUMPERR W/ PRE-RUNNER GUARD



DR10-A2950-1 // 10-15 DODGE HD 2500-5500 BUMPER W/ FULL GUARD



PREMIUM PLATE WINCH BUMPERS
STANDARD FEATURES

THE FAB FOURS PREMIUM PLATE WINCH BUMPER FOCUSES ON STRENGTH AND DURABILITY. THESE BUMPERS ARE DESIGNED TO BE THE ULTIMATE IN FUNCTIONALLY-STYLISH FRONT END PROTECTION WHILE ALSO PROVIDING MORE TIRE CLEARANCE TO ELIMINATE RUBBING. KEY FEATURES INCLUDE THE INTEGRATED FOG AND TURN LIGHTS, AIR DUCTS, D-RING MOUNTS AND ABILITY TO ACCOMMODATE UP TO 16,500 LB. WINCHES. AVAILABLE IN EITHER A FULL GUARD, PRE-RUNNER GUARD OR NO GUARD.

**FAB FOURS INC., MORE THAN EXPECTED,
BETTER THAN EXPECTED.**

FEATURES:

- PROVIDES FAR MORE TIRE CLEARANCE.
- WINCH READY - ACCEPTS UP TO 16,500 LB. WINCHES OR SMALLER (EXCEPT THE WARN POWER-PLANT).
- 3/4" D-RING MOUNTS.
- 1/4" BOXED MOUNTING SYSTEM WITH ADJUSTABILITY TO ALLOW A "CUSTOM" FIT.
- FAB FOURS SIGNATURE INJECTION MOLDED LIGHT HOUSINGS.
- FAB FOURS' 90MM FOG AND 60MM TURN INDICATOR LIGHTS ARE INCLUDED FREE WITH THE BUMPER!





CH14-C3052-1 // 15-16 CHEVY HD SENSOR BUMPER W/ PRE-RUNNER GUARD



TT05-B1552-1 // 05-11 TOYOTA TACOMA W/ PRE-RUNNER GUARD



FJ07-A1750-1 // 07-14 TOYOTA FJ W/ FULL GUARD



FF10-H1962-1 // 10-14 FORD RAPTOR W/ PRE-RUNNER GUARD



TT14-H2852-1 // 14-15 TOYOTA TUNDRA W/ PRE-RUNNER GUARD





FULL SIZE WINCH BUMPERS

PART NUMBER DESCRIPTION (ALL PARTS ARE AVAILABLE BARE STEEL: CH05-A1950-B)

CH05-A1350-1	03 - 07 CLASSIC CHEVY HD 2500 - 3500 BUMPER W/ FULL GUARD
CH05-A1351-1	03 - 07 CLASSIC CHEVY HD 2500 - 3500 BUMPER W/ NO GUARD
CH05-A1352-1	03 - 07 CLASSIC CHEVY HD 2500 - 3500 BUMPER W/ PRE-RUNNER GUARD
CH05-A2351-1	05 - 09 CHEVY / GMC HD 4500 - 8500 BUMPER W/ NO GUARD
CH08-A2050-1	07.5 - 10 CHEVY HD 2500 - 3500 BUMPER W/ FULL GUARD
CH08-A2051-1	07.5 - 10 CHEVY HD 2500 - 3500 BUMPER W/ NO GUARD
CH08-A2052-1	07.5 - 10 CHEVY HD 2500 - 3500 BUMPER W/ PRE-RUNNER GUARD
CS07-H2250-1	07 - 14 SUBURBAN 2500 BUMPER W/ FULL GUARD
CS07-H2251-1	07 - 14 SUBURBAN 2500 BUMPER W/ NO GUARD
CS07-H2252-1	07 - 14 SUBURBAN 2500 BUMPER W/ PRE-RUNNER GUARD
CH11-A2750-1	11 - 14 CHEVY HD 2500 - 3500 BUMPER W/ FULL GUARD
CH11-A2751-1	11 - 14 CHEVY HD 2500 - 3500 BUMPER W/ NO GUARD
CH11-A2752-1	11 - 14 CHEVY HD 2500 - 3500 BUMPER W/ PRE-RUNNER GUARD
CH14-A3050-1	15 - 16 CHEVY HD 2500 - 3500 BUMPER W/ FULL GUARD
CH14-A3051-1	15 - 16 CHEVY HD 2500 - 3500 BUMPER W/ NO GUARD
CH14-A3052-1	15 - 16 CHEVY HD 2500 - 3500 BUMPER W/ PRE-RUNNER GUARD
CH14-C3050-1	15 - 16 CHEVY HD 2500-3500 SENSOR WINCH BUMPER W/ FULL GUARD
CH14-C3051-1	15 - 16 CHEVY HD 2500-3500 SENSOR WINCH BUMPER W/ NO GUARD
CH14-C3052-1	15 - 16 CHEVY HD 2500-3500 SENSOR WINCH BUMPER W/ PRE-RUNNER GUARD
DR94-A1550-1	94 - 02 DODGE HD 2500- 5500 BUMPER W/ FULL GUARD
DR94-A1551-1	94 - 02 DODGE HD 2500- 5500 BUMPER W/ NO GUARD
DR03-A1050-1	03 - 05 DODGE HD 2500- 5500 BUMPER W/ FULL GUARD
DR03-A1051-1	03 - 05 DODGE HD 2500- 5500 BUMPER W/ NO GUARD
DR03-A1052-1	03 - 05 DODGE HD 2500- 5500 BUMPER W/ PRE-RUNNER GUARD
DR06-A1150-1	06 - 09 DODGE HD 2500- 5500 BUMPER W/ FULL GUARD
DR06-A1151-1	06 - 09 DODGE HD 2500- 5500 BUMPER W/ NO GUARD
DR06-A1152-1	06 - 09 DODGE HD 2500- 5500 BUMPER W/ PRE-RUNNER GUARD
DR10-A2950-1	10 - 15 DODGE HD 2500- 5500 BUMPER W/ FULL GUARD
DR10-A2951-1	10 - 15 DODGE HD 2500- 5500 BUMPER W/ NO GUARD
DR10-A2952-1	10 - 15 DODGE HD 2500- 5500 BUMPER W/ PRE-RUNNER GUARD
FS99-A1650-1	99 - 04 FORD SD F250 - F550 BUMPER W/ FULL GUARD
FS99-A1651-1	99 - 04 FORD SD F250 - F550 BUMPER W/ NO GUARD
FS99-A1652-1	99 - 04 FORD SD F250 - F550 BUMPER W/ PRE-RUNNER GUARD
FS05-A1250-1	05 - 07 FORD SD F250 - F550 BUMPER W/ FULL GUARD
FS05-A1251-1	05 - 07 FORD SD F250 - F550 BUMPER W/ NO GUARD

FS05-A1252-1	05 - 07 FORD SD F250 - F550 BUMPER W/ PRE-RUNNER GUARD
FS08-A1950-1	08 - 10 FORD SD F250 - F550 BUMPER W/ FULL GUARD
FS08-A1951-1	08 - 10 FORD SD F250 - F550 BUMPER W/ NO GUARD
FS08-A1952-1	08 - 10 FORD SD F250 - F550 BUMPER W/ PRE-RUNNER GUARD
FS11-A2550-1	11 - 15 FORD SD F250 - F350 BUMPER W/ FULL GUARD
FS11-A2551-1	11 - 15 FORD SD F250 - F350 BUMPER W/ NO GUARD
FS11-A2552-1	11 - 15 FORD SD F250 - F350 BUMPER W/ PRE-RUNNER GUARD
FS11-A2650-1	11 - 15 FORD SD F450 - F550 BUMPER W/ FULL GUARD
FS11-A2651-1	11 - 15 FORD SD F450 - F550 BUMPER W/ NO GUARD
FS11-A2652-1	11 - 15 FORD SD F450 - F550 BUMPER W/ PRE-RUNNER GUARD
GS07-H2350-1	07 - 14 YUKON 2500 BUMPER W/ FULL GUARD
GS07-H2351-1	07 - 14 YUKON 2500 BUMPER W/ NO GUARD
GS07-H2352-1	07 - 14 YUKON 2500 BUMPER W/ PRE-RUNNER GUARD
GM08-A2150-1	07.5 - 10 GMC HD 2500 - 3500 BUMPER W/ FULL GUARD
GM08-A2151-1	07.5 - 10 GMC HD 2500 - 3500 BUMPER W/ NO GUARD
GM08-A2152-1	07.5 - 10 GMC HD 2500 - 3500 BUMPER W/ PRE-RUNNER GUARD
GM11-A2850-1	11 - 14 GMC HD 2500 - 3500 BUMPER W/ FULL GUARD
GM11-A2851-1	11 - 14 GMC HD 2500 - 3500 BUMPER W/ NO GUARD
GM11-A2852-1	11 - 14 GMC HD 2500 - 3500 BUMPER W/ PRE-RUNNER GUARD
GM14-A3150-1	15 - 16 GMC HD 2500 - 3500 BUMPER W/ FULL GUARD
GM14-A3151-1	15 - 16 GMC HD 2500 - 3500 BUMPER W/ NO GUARD
GM14-A3152-1	15 - 16 GMC HD 2500 - 3500 BUMPER W/ PRE-RUNNER GUARD
GM14-C3150-1	15 - 16 GMC HD 2500-3500 SENSOR WINCH BUMPER W/ FULL GUARD
GM14-C3151-1	15 - 16 GMC HD 2500-3500 SENSOR WINCH BUMPER W/ NO GUARD
GM14-C3152-1	15 - 16 GMC HD 2500-3500 SENSOR WINCH BUMPER W/ PRE-RUNNER GUARD

1/2 TON WINCH BUMPERS

PART NUMBER	DESCRIPTION
CS07-H2240-1	07 - 14 CHEVY SUBURBAN / TAHOE 1500 W/ FULL GUARD
CS07-H2241-1	07 - 14 CHEVY SUBURBAN / TAHOE 1500 W/ NO GUARD
CS07-H2242-1	07 - 14 CHEVY SUBURBAN / TAHOE 1500 W/ PRE-RUNNER GUARD
CS07-H2050-1	07 - 13 CHEVY 1500 BUMPER W/ FULL GUARD
CS07-H2051-1	07 - 13 CHEVY 1500 BUMPER W/ NO GUARD
CS07-H2052-1	07 - 13 CHEVY 1500 BUMPER W/ PRE-RUNNER GUARD
CS14-H3050-1	14 - 15 CHEVY 1500 BUMPER W/ FULL GUARD
CS14-H3051-1	14 - 15 CHEVY 1500 BUMPER W/ NO GUARD

CS14-H3052-1	14 - 15 CHEVY 1500 BUMPER W/ PRE-RUNNER GUARD
GS07-H2340-1	07 - 14 YUKON / YUK. XL 1500 BUMPER W/ FULL GUARD
GS07-H2341-1	07 - 14 YUKON / YUK. XL 1500 BUMPER W/ NO GUARD
GS07-H2342-1	07 - 14 YUKON / YUK. XL 1500 BUMPER W/ PRE-RUNNER GUARD
GS07-H2150-1	07 - 13 GMC 1500 BUMPER W/ FULL GUARD
GS07-H2151-1	07 - 13 GMC 1500 BUMPER W/ NO GUARD
GS07-H2152-1	07 - 13 GMC 1500 BUMPER W/ PRE-RUNNER GUARD
GS14-H3150-1	14 - 15 GMC 1500 BUMPER W/ FULL GUARD
GS14-H3151-1	14 - 15 GMC 1500 BUMPER W/ NO GUARD
GS14-H3152-1	14 - 15 GMC 1500 BUMPER W/ PRE-RUNNER GUARD
DR09-H2450-1	09 - 12 DODGE 1500 BUMPER W/ FULL GUARD
DR09-H2451-1	09 - 12 DODGE 1500 BUMPER W/ NO GUARD
DR09-H2452-1	09 - 12 DODGE 1500 BUMPER W/ PRE-RUNNER GUARD
DR13-H2950-1	13-15 DODGE 1500 WINCH BUMPER W/ FULL GUARD
DR13-H2951-1	13-15 DODGE 1500 WINCH BUMPER W/ NO GUARD
DR13-H2952-1	13-15 DODGE 1500 WINCH BUMPER W/ PRE-RUNNER GUARD
DR13-F2950-1	13-15 DODGE 1500 SENSOR WINCH BUMPER W/ FULL GUARD
DR13-F2951-1	13-15 DODGE 1500 SENSOR WINCH BUMPER W/ NO GUARD
DR13-F2952-1	13-15 DODGE 1500 SENSOR WINCH BUMPER W/ PRE-RUNNER GUARD
FF09-H1950-1	09 - 14 FORD F150 BUMPER W/ FULL GUARD
FF09-H1951-1	09 - 14 FORD F150 BUMPER W/ NO GUARD
FF09-H1952-1	09 - 14 FORD F150 BUMPER W/ PRE-RUNNER GUARD
FF10-H1960-1	10 - 14 FORD RAPTOR BUMPER W/ FULL GUARD
FF10-H1961-1	10 - 14 FORD RAPTOR BUMPER W/ NO GUARD
FF10-H1962-1	10 - 14 FORD RAPTOR BUMPER W/ PRE-RUNNER GUARD
FF15-H3250-1	15 - 16 FORD F150 WINCH BUMPER W/ FULL GUARD
FF15-H3251-1	15 - 16 FORD F150 WINCH BUMPER W/ NO GUARD
FF15-H3252-1	15 - 16 FORD F150 WINCH BUMPER W/ PRE-RUNNER GUARD
FF15-F3250-1	15 - 16 FORD F150 SENSOR WINCH BUMPER W/ FULL GUARD
FF15-F3251-1	15 - 16 FORD F150 SENSOR WINCH BUMPER W/ NO GUARD
FF15-F3252-1	15 - 16 FORD F150 SENSOR WINCH BUMPER W/ PRE-RUNNER GUARD
FF15-D3251-1	15 - 16 FORD F150 DESERT SERIES LIGHT BUMPER W/ NO GUARD
FF15-D3252-1	15 - 16 FORD F150 DESERT SERIES LIGHT BUMPER W/ GUARD
NT04-H1751-1	04 - 14 NISSAN TITAN BUMPER W/ NO GUARD
NT04-H1752-1	04 - 14 NISSAN TITAN BUMPER W/ PRE-RUNNER GUARD
TT07-H1851-1	07 - 13 TOYOTA TUNDRA BUMPER W/ NO GUARD
TT07-H1852-1	07 - 13 TOYOTA TUNDRA BUMPER W/ PRE-RUNNER GUARD
TT14-H2851-1	14 - 15 TOYOTA TUNDRA BUMPER W/ NO GUARD
TT14-H2852-1	14 - 15 TOYOTA TUNDRA BUMPER W/ PRE-RUNNER GUARD
TT05-B1550-1	05 - 11 TOYOTA TACOMA BUMPER W/ FULL GUARD
TT05-B1551-1	05 - 11 TOYOTA TACOMA BUMPER W/ NO GUARD
TT05-B1552-1	05 - 11 TOYOTA TACOMA BUMPER W/ PRE-RUNNER GUARD
TT12-B1650-1	12 - 15 TOYOTA TACOMA BUMPER W/ FULL GUARD
TT12-B1651-1	12 - 15 TOYOTA TACOMA BUMPER W/ NO GUARD
TT12-B1652-1	12 - 15 TOYOTA TACOMA BUMPER W/ PRE-RUNNER GUARD
FJ07-A1750-1	07 - 14 TOYOTA FJ BUMPER W/ FULL GUARD
FJ07-A1751-1	07 - 14 TOYOTA FJ BUMPER W/ NO GUARD
FJ07-A1752-1	07 - 14 TOYOTA FJ BUMPER W/ PRE-RUNNER GUARD

REAR BUMPERS

PART NUMBER	DESCRIPTION
CH99-W1250-1	99 - 07 CLASSIC CHEVY / GMC HD 2500 - 3500 REAR BUMPER
CH08-W1450-1	07.5 - 10 CHEVY / GMC HD 2500 - 3500 REAR BUMPER
CH11-W2150-1	11 - 14 CHEVY / GMC HD 2500 - 3500 REAR BUMPER
CH14-W3050-1	15 - 16 CHEVY/ GMC HD 2500 - 3500 REAR BUMPER
CH14-W3051-1	15 - 16 CHEVY / GMC HD 2500-3500 SENSOR REAR BUMPER
CS07-W1850-1	07 - 13 CHEVY / GMC 1500 REAR BUMPER
CS14-W3150-1	14 - 15 CHEVY / GMC 1500 REAR BUMPER
CS07-W2250-1	07 - 14 1500-2500 SUBURBAN / YUKON XL REAR BUMPER
CS07-W2251-1	07 - 14 1500-2500 SUBURBAN / YUKON XL SENSOR REAR BUMPER
CS07-W2240-1	07 - 14 TAHOE / YUKON 1500 REAR BUMPER
CS07-W2241-1	07 - 14 TAHOE / YUKON 1500 SENSOR REAR BUMPER
DR94-W1650-1	94 - 02 DODGE HD 2500 - 3500 REAR BUMPER
DR03-W1050-1	03 - 09 DODGE HD 2500 - 3500 REAR BUMPER
DR09-W2050-1	09 - 12 DODGE 1500 10 - 12 DODGE HD 2500 - 3500 REAR BUMPER
DR09-W2051-1	09 - 12 DODGE 1500 W/ DUAL EXHAUST REAR BUMPER
DR09-W2950-1	10 - 15 DODGE HD 2500 - 3500 REAR BUMPER
DR09-W2952-1	09 - 15 DODGE 1500 SENSOR REAR W/ DUAL EXHAUST 10 - 15 DODGE HD 2500 - 3500 SENSOR REAR BUMPER
FS08-W1350-1	99 - 15 FORD SD F250 - F350 REAR BUMPER
FS08-W1351-1	99 - 15 FORD SD F250 - F350 SENSOR REAR BUMPER
FF09-W1750-1	09 - 14 FORD F150 REAR BUMPER
FF15-W3250-1	15 - 16 FORD F150 REAR BUMPER
FF15-W3251-1	15 - 16 FORD F150 SENSOR REAR BUMPER
FF15-W3252-1	15 - 16 FORD F150 DESERT SERIES LIGHT REAR BUMPER
NT04-W1950-1	04 - 14 NISSAN TITAN REAR BUMPER
FJ07-Y1150-1	07 - 14 TOYOTA FJ REAR BUMPER W/ TIRE CARRIER
TT07-W1550-1	07 - 13 TOYOTA TUNDRA REAR BUMPER
TT14-W2850-1	14 - 15 TOYOTA TUNDRA REAR BUMPER
TT05-Y1351-1	05 - 15 TOYOTA TACOMA REAR BASE BUMPER
TT-Y1351T-1	05 - 15 TOYOTA TACOMA TIRE CARRIER (NEEDS BASE BUMPER)

ACCESSORIES

PART NUMBER	DESCRIPTION
P1250-1	DANA 44 DIFF COVER
P1350-1	DANA 60 DIFF COVER
P1450-1	14 BOLT DIFF COVER
M1250-1	2" FRONT RECEIVER HITCH ADAPTER
M1950-1	08 - 10 FORD F450 - F550 BUMPER EXTENSION CAPS
61349	60MM TURN SIGNAL WITH WIRING
61350	90MM FOG LIGHT WITH WIRING
20090	PLASTIC LIGHT INSERT (QUANTITY 1)
H84994031	HELLA FOG LIGHT HARNESS FOR VEHICLES WITH FACTORY FOGS
1378127	1378 BLACK LICENSE PLATE LAMP (DODGE REAR BUMPER ONLY)
JKST-LR	OPTIONAL FOG LIGHT KIT FOR THE JK STUBBY FRONT BUMPER (B1853 AND B1854)
WB0027SPAD	LAW ENFORCEMENT PUSH BAR PB200 BUMPER LOOP 16IN STEEL W/PAO (PAIR)



JK07-B1856-1 // JEEP JK FMJ STUBBY BUMPER W/ FULL GUARD
JK07-B1859-1 // JEEP JK MODIFIER



JK07-Y1251-1 // JEEP JK REAR BASE BUMPER [NO TIRE CARRIER]
JP-Y1251T-1 // JEEP TJ / LJ / JK REAR TIRE CARRIER [NEEDS BASE BUMPER]

JEEP FULL METAL JACKET

- ▶▶▶ STUBBY AND FULL WIDTH BUMPER VERSIONS AVAILABLE.
- ▶▶▶ BUMPER AND WINCH MODIFIER ACCEPT 2X2 RIGID INDUSTRIES DUALY LIGHTS [BUMPER FITS FACTORY FOGS]
- ▶▶▶ STYLING FEATURES ENHANCE THE NEW WARN 'ZEON' WINCHES [FITS OTHER WINCHES AS WELL]





JK07-B1854-1 // JEEP JK HARDCORE STUBBY BUMPER W/ FULL GUARD

JK07-B1850-1 // JEEP JK LIFESTYLE BUMPER W/ PRE-RUNNER GUARD



JP-Y1261T-1 // JEEP JK OFF-THE-DOOR TIRE CARRIER



JEEP BUMPERS

PART NUMBER DESCRIPTION [ALL PARTS ARE AVAILABLE BARE STEEL : JK07-B1850-B]

JP97-B1450-1	97 - 06 JEEP TJ / LJ HARDCORE BUMPER W/ STINGER GUARD
JP97-B1451-1	97 - 06 JEEP TJ / LJ LIFESTYLE BUMPER W/ NO GUARD
JP97-B1452-1	97 - 06 JEEP TJ / LJ LIFESTYLE BUMPER W/ PRE-RUNNER GUARD
JK07-B1850-1	07 - 15 JEEP JK LIFESTYLE BUMPER W/ PRE-RUNNER GUARD
JK07-B1851-1	07 - 15 JEEP JK LIFESTYLE BUMPER W/ NO GUARD
JK07-B1853-1	07 - 15 JEEP JK HARDCORE STUBBY BUMPER W/ NO GUARD
JK07-B1854-1	07 - 15 JEEP JK HARDCORE STUBBY BUMPER W/ FULL GUARD
JK07-B1855-1	07 - 15 JEEP JK FMJ STUBBY BUMPER W/ NO GUARD
JK07-B1856-1	07 - 15 JEEP JK FMJ STUBBY BUMPER W/ FULL GUARD
JK07-B1857-1	07 - 15 JEEP JK FMJ FULL WIDTH BUMPER W/ NO GUARD
JK07-B1858-1	07 - 15 JEEP JK FMJ FULL WIDTH BUMPER W/ FULL GUARD
JK07-B1859-1	07 - 15 JEEP JK FMJ MODIFIER
JPWP-1	07 - 15 JEEP JK WINCH PLATE (REQUIRED IF USING A WINCH W/ OUT FMJ MODIFIER)

JEEP REAR BUMPERS [TIRE CARRIERS]

PART NUMBER	DESCRIPTION
JP97-Y1051-1	97 - 06 JEEP TJ / LJ REAR BASE BUMPER (NO TIRE CARRIER)
JK07-Y1251-1	07 - 15 JEEP JK REAR BASE BUMPER (NO TIRE CARRIER)
JP-Y1251T-1	97 - 15 JEEP TJ / LJ / JK REAR TIRE CARRIER (NEEDS BASE BUMPER)
JP-Y1261T-1	07 - 15 JEEP JK OFF-THE-DOOR TIRE CARRIER (NEEDS BASE BUMPER)
M1450-1	FAB FOURS TIRE CARRIER (JP-Y1251T-1) HI LIFT JACK MOUNT
M2050-1	07 - 15 JEEP JK 3RD BRAKE LIGHT (NEEDS JP-Y1261T-1)
M2150-1	07 - 15 JEEP JK HI-LIFT MOUNT (NEEDS JP-Y1261T-1)

ROCK SLIDERS

PART NUMBER	DESCRIPTION
LJ05-G1150-1	04 - 06 JEEP LJ ROCK SLIDERS
LJ05-G1151-1	04 - 06 JEEP LJ ROCK SLIDERS W/ NO TUBE
TJ97-G1050-1	97 - 06 JEEP TJ ROCK SLIDERS
TJ97-G1051-1	97 - 06 JEEP TJ ROCK SLIDERS W/ NO TUBE
JK07-G1250-1	07 - 15 JEEP JK 4 DOOR ROCK SLIDERS
JK07-G1350-1	07 - 15 JEEP JK 2 DOOR ROCK SLIDERS





RR48-1 // 48 INCH MODULAR ROOF RACK



HR2000-1 // 07-15 CHEVY/GMC 1500-3500 HEADACHE RACK



J1034-1 // 99-15 FORD F250-F350 SD CREW CAB SIDE STEPS LENGTH 4

ROOF RACKS

PART NUMBER	DESCRIPTION
RR48-1	48 INCH MODULAR ROOF RACK
RR60-1	60 INCH MODULAR ROOF RACK
RR72-1	72 INCH MODULAR ROOF RACK

WINCH MOUNT

PART NUMBER	DESCRIPTION
DR09-N2650-1	09 - 12 DODGE 1500 WINCH MOUNT
DR10-N2450-1	03 - 15 DODGE 2500 - 3500 WINCH MOUNT
DR10-N2460-1	03 - 15 DODGE 2500 - 3500 LARGE FRAME WINCH MOUNT
FS99-N1650-1	99 - 04 FORD SD F250 - F550 WINCH MOUNT
FS05-N1250-1	05 - 07 FORD SD F250 - F550 WINCH MOUNT
FS08-N1950-1	08 - 10 FORD SD F250 - F550 WINCH MOUNT
FS11-N2550-1	11 - 15 FORD SD F250 - F550 WINCH MOUNT
FS11-N2560-1	11 - 15 FORD SD F250 - F550 LARGE FRAME WINCH MOUNT
FS09-N1450-1	09 - 14 FORD F150 WINCH MOUNT
GM05-N1350-1	03 - 07 CLASSIC CHEVY / GMC 2500 - 3500 WINCH MOUNT
GM07-N2050-1	07 - 13 CHEVY / GMC 1500 WINCH MOUNT
GM08-N2150-1	07.5 - 10 CHEVY / GMC 2500 - 3500 WINCH MOUNT
GM11-N2750-1	11 - 14 CHEVY / GMC 2500 - 3500 WINCH MOUNT
GM11-N2760-1	11 - 14 CHEVY / GMC 2500 - 3500 LARGE FRAME WINCH MOUNT
GM14-N3150-1	14 - 15 CHEVY / GMC 1500 WINCH MOUNT
GM15-N3060-1	15 - 16 CHEVY / GMC 2500 - 3500 LARGE FRAME WINCH MOUNT
NT04-N1750-1	04 - 14 NISSAN TITAN WINCH MOUNT
TT07-N1850-1	07 - 13 TOYOTA TUNDRA WINCH MOUNT

FS11-N2550-1 // 11-15 FORD F250-F550 SD WINCH MOUNT

HEADACHE RACK

PART NUMBER	DESCRIPTION
HR2000-1	07 - 15 CHEVY / GMC 1500 - 3500 HEADACHE RACK
HR2001-1	03 - 06 CHEVY / GMC 1500 - 3500 HEADACHE RACK
HR2002-1	03 - 15 DODGE 1500 - 3500 HEADACHE RACK
HR2004-1	94 - 02 DODGE 1500 - 3500 HEADACHE RACK
HR2005-1	99 - 15 FORD SD F250 - F350 HEADACHE RACK
HR2006-1	09 - 14 FORD F150 HEADACHE RACK
HR2008-1	07 - 15 TOYOTA TUNDRA HEADACHE RACK

SIDE STEP

PART NUMBER	DESCRIPTION
J1017	01 - 06 CHEVY / GMC 1500 - 3500 CREW CAB CAB LENGTH 4
J1011	07 - 10 CHEVY / GMC 1500 - 3500 CREW CAB CAB LENGTH 4
J1006	11 - 16 CHEVY / GMC 1500 - 3500 CREW CAB CAB LENGTH 4
J1010	11 - 13 CHEVY / GMC 2500 - 3500 HD CREW CAB CAB LENGTH 4 (DIESEL)
J1020	02 - 09 DODGE RAM QUAD CAB CAB LENGTH 4
J1024	09 - 15 DODGE 1500 - 3500 CREW CAB CAB LENGTH 4
J1029	10 - 15 DODGE 2500 - 3500 MEGA 4
J1030	09 - 14 FORD F150 CREW CAB CAB LENGTH 4
J1033	10 - 14 FORD F150 RAPTOR 4
J1034	99 - 15 FORD F250 - F350 CREW CAB CAB LENGTH 4
J1001	07 - 15 JEEP JK 2 DOOR
J1002	07 - 15 JEEP JK 4 DOOR
J1003	05 - 15 TOYOTA TACOMA DUAL CAB CAB LENGTH
J1004	07 - 14 TOYOTA FJ CRUISER 4
J1037	07 - 15 TOYOTA TUNDRA DUAL CAB CAB LENGTH 4
J1040	07 - 15 TOYOTA TUNDRA CREW MAX CAB LENGTH 4



BLACK STEEL.
ELITE

WE TOOK THE 'RANCH' BUMPER DESIGN AND COMBINED IT WITH THE SMOOTH PLATE LOOK FROM OUR PREMIUM LINE TO CREATE BLACK STEEL **ELITE**. NO GRILLE MESH AND PREMIUM POWDER COAT GIVE THE ELITE BUMPERS A UNIQUE LOOK. LIKE ALL FAB FOURS' PRODUCTS WE MATCHED EVERY BUMPER TO THE BODY LINES OF EACH MODEL TRUCK. THE ELITE SERIES IS A WHOLE NEW LOOK WITH THE SAME FAB FOURS' QUALITY. AVAILABLE IN EITHER A FULL GUARD, PRE-RUNNER GUARD OR NO GUARD BUMPER FOR BOTH HD AND 1/2 TON TRUCK MODELS.



DODGE 3500 // ELITE PRE-RUNNER GUARD



FORD SUPER DUTY // ELITE NO GUARD

STANDARD FEATURES:

12 GAUGE STEEL CONSTRUCTION

TOW HOOKS

ACCEPTS FACTORY FOG LIGHTS

POWDER COATED MATTE BLACK

OPTIONAL - BOLT ON WINCH MOUNT

16,500 LB. WINCHES OR SMALLER
12,000 LB. WINCHES FOR 1/2 TONS

OPTIONAL - BOLT ON D-RING MOUNTS

OPTIONAL - BOLT ON 2-INCH RECEIVER



CHEVY 2500 HD // ELITE FULL GUARD



TOYOTA TUNDRA // ELITE PRE-RUNNER GUARD

FULL SIZE REPLACEMENT BUMPERS

PART NUMBER **DESCRIPTION** [ALL PARTS ARE AVAILABLE BARE STEEL : CH05-Q1360-B]

CH05-Q1360-1	03 - 07 CLASSIC CHEVY HD 2500 - 3500 ELITE BUMPER W/ FULL GUARD
CH05-Q1361-1	03 - 07 CLASSIC CHEVY HD 2500 - 3500 ELITE BUMPER W/ NO GUARD
CH05-Q1362-1	03 - 07 CLASSIC CHEVY HD 2500 - 3500 ELITE BUMPER W/ PRE-RUNNER GUARD
CH08-Q2060-1	07.5 - 10 CHEVY HD 2500 - 3500 ELITE BUMPER W/ FULL GUARD
CH08-Q2061-1	07.5 - 10 CHEVY HD 2500 - 3500 ELITE BUMPER W/ NO GUARD
CH08-Q2062-1	07.5 - 10 CHEVY HD 2500 - 3500 ELITE BUMPER W/ PRE-RUNNER GUARD
CH11-Q2760-1	11 - 14 CHEVY HD 2500 - 3500 ELITE BUMPER W/ FULL GUARD
CH11-Q2761-1	11 - 14 CHEVY HD 2500 - 3500 ELITE BUMPER W/ NO GUARD
CH11-Q2762-1	11 - 14 CHEVY HD 2500 - 3500 ELITE BUMPER W/ PRE-RUNNER GUARD
CH14-Q3060-1	15 - 16 CHEVY HD 2500 - 3500 ELITE BUMPER W/ FULL GUARD
CH14-Q3061-1	15 - 16 CHEVY HD 2500 - 3500 ELITE BUMPER W/ NO GUARD
CH14-Q3062-1	15 - 16 CHEVY HD 2500 - 3500 ELITE BUMPER W/ PRE-RUNNER GUARD
DR94-Q1560-1	94 - 02 DODGE HD 2500 - 5500 ELITE BUMPER W/ FULL GUARD
DR94-Q1561-1	94 - 02 DODGE HD 2500 - 5500 ELITE BUMPER W/ NO GUARD
DR94-Q1562-1	94 - 02 DODGE HD 2500 - 5500 ELITE BUMPER W/ PRE-RUNNER GUARD
DR03-Q1060-1	03 - 05 DODGE HD 2500 - 5500 ELITE BUMPER W/ FULL GUARD
DR03-Q1061-1	03 - 05 DODGE HD 2500 - 5500 ELITE BUMPER W/ NO GUARD
DR03-Q1062-1	03 - 05 DODGE HD 2500 - 5500 ELITE BUMPER W/ PRE-RUNNER GUARD
DR06-Q1160-1	06 - 09 DODGE HD 2500 - 5500 ELITE BUMPER W/ FULL GUARD
DR06-Q1161-1	06 - 09 DODGE HD 2500 - 5500 ELITE BUMPER W/ NO GUARD
DR06-Q1162-1	06 - 09 DODGE HD 2500 - 5500 ELITE BUMPER W/ PRE-RUNNER GUARD
DR10-Q2960-1	10 - 15 DODGE HD 2500 - 5500 ELITE BUMPER W/ FULL GUARD
DR10-Q2961-1	10 - 15 DODGE HD 2500 - 5500 ELITE BUMPER W/ NO GUARD
DR10-Q2962-1	10 - 15 DODGE HD 2500 - 5500 ELITE BUMPER W/ PRE-RUNNER GUARD
FS99-Q1660-1	99 - 04 FORD SD F250 - F350 ELITE BUMPER W/ FULL GUARD
FS99-Q1661-1	99 - 04 FORD SD F250 - F550 ELITE BUMPER W/ NO GUARD
FS99-Q1662-1	99 - 04 FORD SD F250 - F550 ELITE BUMPER W/ PRE-RUNNER GUARD
FS05-Q1260-1	05 - 07 FORD SD F250 - F350 ELITE BUMPER W/ FULL GUARD

FS05-Q1261-1	05 - 07 FORD SD F250 - F550 ELITE BUMPER W/ NO GUARD
FS05-Q1262-1	05 - 07 FORD SD F250 - F550 ELITE BUMPER W/ PRE-RUNNER GUARD
FS08-Q1960-1	08 - 10 FORD SD F250 - F350 ELITE BUMPER W/ FULL GUARD
FS08-Q1961-1	08 - 10 FORD SD F250 - F550 ELITE BUMPER W/ NO GUARD
FS08-Q1962-1	08 - 10 FORD SD F250 - F550 ELITE BUMPER W/ PRE-RUNNER GUARD
FS11-Q2560-1	11 - 15 FORD SD F250 - F550 ELITE BUMPER W/ FULL GUARD
FS11-Q2561-1	11 - 15 FORD SD F250 - F550 ELITE BUMPER W/ NO GUARD
FS11-Q2562-1	11 - 15 FORD SD F250 - F550 ELITE BUMPER W/ PRE-RUNNER GUARD
GM08-Q2160-1	07.5 - 10 GMC HD 2500 - 3500 ELITE BUMPER W/ FULL GUARD
GM08-Q2161-1	07.5 - 10 GMC HD 2500 - 3500 ELITE BUMPER W/ NO GUARD
GM08-Q2162-1	07.5 - 10 GMC HD 2500 - 3500 ELITE BUMPER W/ PRE-RUNNER GUARD
GM11-Q2860-1	11 - 14 GMC HD 2500 - 3500 ELITE BUMPER W/ FULL GUARD
GM11-Q2861-1	11 - 14 GMC HD 2500 - 3500 ELITE BUMPER W/ NO GUARD
GM11-Q2862-1	11 - 14 GMC HD 2500 - 3500 ELITE BUMPER W/ PRE-RUNNER GUARD
GM14-Q3160-1	15 - 16 GMC HD 2500 - 3500 ELITE BUMPER W/ FULL GUARD
GM14-Q3161-1	15 - 16 GMC HD 2500 - 3500 ELITE BUMPER W/ NO GUARD
GM14-Q3162-1	15 - 16 GMC HD 2500 - 3500 ELITE BUMPER W/ PRE-RUNNER GUARD

1/2 TON REPLACEMENT BUMPERS

PART NUMBER	DESCRIPTION
CS07-R2060-1	07 - 13 CHEVY 1500 ELITE BUMPER W/ FULL GUARD
CS07-R2061-1	07 - 13 CHEVY 1500 ELITE BUMPER W/ NO GUARD
CS07-R2062-1	07 - 13 CHEVY 1500 ELITE BUMPER W/ PRE-RUNNER GUARD
CS14-R3060-1	14 - 15 CHEVY 1500 ELITE BUMPER W/ FULL GUARD
CS14-R3061-1	14 - 15 CHEVY 1500 ELITE BUMPER W/ NO GUARD
CS14-R3062-1	14 - 15 CHEVY 1500 ELITE BUMPER W/ PRE-RUNNER GUARD
DR09-R2460-1	09 - 12 DODGE 1500 ELITE BUMPER W/ FULL GUARD
DR09-R2461-1	09 - 12 DODGE 1500 ELITE BUMPER W/ NO GUARD

DR09-R2462-1	09 - 12 DODGE 1500 ELITE BUMPER W/ PRE-RUNNER GUARD
DR13-R2960-1	13 - 15 DODGE 1500 ELITE BUMPER W/ FULL GUARD
DR13-R2961-1	13 - 15 DODGE 1500 ELITE BUMPER W/ NO GUARD
DR13-R2962-1	13 - 15 DODGE 1500 ELITE BUMPER W/ PRE-RUNNER GUARD
FF09-R1960-1	09 - 13 FORD F150 ELITE BUMPER W/ FULL GUARD
FF09-R1961-1	09 - 13 FORD F150 ELITE BUMPER W/ NO GUARD
FF09-R1962-1	09 - 13 FORD F150 ELITE BUMPER W/ PRE-RUNNER GUARD
FF15-R3250-1	15 - 16 FORD F150 ELITE BUMPER FULL GUARD
FF15-R3251-1	15 - 16 FORD F150 ELITE BUMPER NO GUARD
FF15-R3252-1	15 - 16 FORD F150 ELITE BUMPER PRE-RUNNER GUARD
GM07-R2160-1	07 - 13 GMC 1500 ELITE BUMPER W/ FULL GUARD
GM07-R2161-1	07 - 13 GMC 1500 ELITE BUMPER W/ NO GUARD
GM07-R2162-1	07 - 13 GMC 1500 ELITE BUMPER W/ PRE-RUNNER GUARD
GS14-R3160-1	14 - 15 GMC 1500 ELITE BUMPER W/ FULL GUARD
GS14-R3161-1	14 - 15 GMC 1500 ELITE BUMPER W/ NO GUARD
GS14-R3162-1	14 - 15 GMC 1500 ELITE BUMPER W/ PRE-RUNNER GUARD
NT04-R1760-1	04 - 14 NISSAN TITAN ELITE BUMPER W/ FULL GUARD
NT04-R1761-1	04 - 14 NISSAN TITAN ELITE BUMPER W/ NO GUARD
NT04-R1762-1	04 - 14 NISSAN TITAN ELITE BUMPER W/ PRE-RUNNER GUARD

TT07-R1860-1	07 - 13 TOYOTA TUNDRA ELITE BUMPER W/ FULL GUARD
TT07-R1861-1	07 - 13 TOYOTA TUNDRA ELITE BUMPER W/ NO GUARD
TT07-R1862-1	07 - 13 TOYOTA TUNDRA ELITE BUMPER W/ PRE-RUNNER GUARD
TT14-R2860-1	14 - 15 TOYOTA TUNDRA ELITE BUMPER W/ FULL GUARD
TT14-R2861-1	14 - 15 TOYOTA TUNDRA ELITE BUMPER W/ NO GUARD
TT14-R2862-1	14 - 15 TOYOTA TUNDRA ELITE BUMPER W/ PRE-RUNNER GUARD

REAR BUMPERS

PART NUMBER	DESCRIPTION
CH99-U1250-1	01 - 07 CLASSIC CHEVY / GMC HD 2500 - 3500 ELITE REAR BUMPER
CH08-U1450-1	07.5 - 10 CHEVY / GMC HD 2500 - 3500 ELITE REAR BUMPER
CH11-U2150-1	11 - 14 CHEVY / GMC HD 2500 - 3500 ELITE REAR BUMPER
CH14-U3050-1	15 - 16 CHEVY / GMC HD 2500 - 3500 ELITE REAR BUMPER
CS07-U1850-1	07 - 13 CHEVY / GMC 1500 ELITE REAR BUMPER
CS14-U3150-1	14 - 15 CHEVY / GMC 1500 ELITE REAR BUMPER
DR94-U1650-1	94 - 02 DODGE HD 2500 - 3500 ELITE REAR BUMPER
DR03-U1050-1	03 - 09 DODGE HD 2500 - 3500 ELITE REAR BUMPER
DR10-U2950-1	10 - 15 DODGE HD 2500 - 3500 ELITE REAR BUMPER
FS08-U1350-1	99 - 15 FORD SD F250 - F350 ELITE REAR BUMPER
FF09-U1750-1	09 - 14 FORD F150 ELITE REAR BUMPER
FF15-U3250-1	15 - 16 FORD F150 ELITE REAR BUMPER
NT04-U1950-1	04 - 14 NISSAN TITAN ELITE REAR BUMPER
TT07-U1550-1	07 - 13 TOYOTA TUNDRA ELITE REAR BUMPER
TT14-U2850-1	14 - 15 TOYOTA TUNDRA ELITE REAR BUMPER

ACCESSORIES

PART NUMBER	DESCRIPTION
QWINCH-1	ELITE WINCH TRAY (FITS ALL FULL SIZE BLACK STEEL FRONT BUMPERS)
RWINCH-1	1/2 TON ELITE WINCH TRAY
OREC-1	ELITE 2" RECEIVER (FITS ALL FULL SIZE BLACK STEEL FRONT BUMPERS)
ORING-1	ELITE O-RING MOUNTS (FITS ALL BLACK STEEL FRONT BUMPERS) QUANTITY 2
BSTOWHOOK	BLACK STEEL TOW HOOKS
QGAIR-1	ELITE HI-FLOW LOWER GUARD
QLITE-1	ELITE LIGHT LOWER GUARD

BLACK STEEL™

WE TOOK THE 'RANCH' BUMPER AND GAVE IT THE UNIQUE STYLING AND DESIGN THAT WE ARE KNOWN FOR IN OUR HEAVY DUTY PLATE BUMPERS. WE MATCHED EVERY BUMPER TO THE BODY LINES OF EACH MODEL TRUCK. WITH NO VERTICAL FLANGES AND TAPERED EDGES THE STANDARD 'RANCH' BUMPER JUST GOT A WHOLE NEW LOOK WITH THE SAME 'FAB FOURS' QUALITY. AVAILABLE IN EITHER A FULL GUARD, PRE-RUNNER GUARD OR NO GUARD FOR BOTH HD AND 1/2 TON TRUCK MODELS.



CHEVY HD // BLACK STEEL NO GUARD



GMC 1500 // BLACK STEEL PRE-RUNNER GUARD

STANDARD FEATURES:

14 GAUGE STEEL CONSTRUCTION
TOW HOOKS
ACCEPTS FACTORY FOG LIGHTS
POWDER COATED GLOSS BLACK

OPTIONAL - BOLT ON WINCH MOUNT

[16,500 LB. WINCHES OR SMALLER]
[12,000 LB. WINCHES FOR 1/2 TONS]

OPTIONAL - BOLT ON D-RING MOUNTS

OPTIONAL - BOLT ON 2-INCH RECEIVER

Houston

SHOWING THE COMPANY'S LAND OFFICES OF THE GENERAL LAND OFFICE

BLACK STEEL™



FORD SUPER DUTY // BLACK STEEL FULL GUARD

1/2 TON REPLACEMENT BUMPERS

PART NUMBER	DESCRIPTION
CS07-K2060-1	07-13 CHEVY 1500 BS BUMPER W/ FULL GUARD
CS07-K2061-1	07-13 CHEVY 1500 BS BUMPER W/ NO GUARD
CS07-K2062-1	07-13 CHEVY 1500 BS BUMPER W/ PRE-RUNNER GUARD
CS14-K3060-1	14-15 CHEVY 1500 BS BUMPER W/ FULL GUARD
CS14-K3061-1	14-15 CHEVY 1500 BS BUMPER W/ NO GUARD
CS14-K3062-1	14-15 CHEVY 1500 BS BUMPER W/ PRE-RUNNER GUARD
DR09-K2460-1	09-12 DODGE 1500 BS BUMPER W/ FULL GUARD
DR09-K2461-1	09-12 DODGE 1500 BS BUMPER W/ NO GUARD
DR09-K2462-1	09-12 DODGE 1500 BS BUMPER W/ PRE-RUNNER GUARD
DR13-K2960-1	13-15 DODGE 1500 BS BUMPER W/ FULL GUARD
DR13-K2961-1	13-15 DODGE 1500 BS BUMPER W/ NO GUARD
DR13-K2962-1	13-15 DODGE 1500 BS BUMPER W/ PRE-RUNNER GUARD
FF09-K1960-1	09-14 FORD F150 BS BUMPER W/ FULL GUARD
FF09-K1961-1	09-14 FORD F150 BS BUMPER W/ NO GUARD
FF09-K1962-1	09-14 FORD F150 BS BUMPER W/ PRE-RUNNER GUARD
FF15-K3250-1	15-16 FORD F150 BS BUMPER FULL GUARD
FF15-K3251-1	15-16 FORD F150 BS BUMPER NO GUARD
FF15-K3252-1	15-16 FORD F150 BS BUMPER PRE-RUNNER GUARD
GM07-K2160-1	07-13 GMC 1500 BS BUMPER W/ FULL GUARD
GM07-K2161-1	07-13 GMC 1500 BS BUMPER W/ NO GUARD
GM07-K2162-1	07-13 GMC 1500 BS BUMPER W/ PRE-RUNNER GUARD
GS14-K3160-1	14-15 GMC 1500 BS BUMPER W/ FULL GUARD
GS14-K3161-1	14-15 GMC 1500 BS BUMPER W/ NO GUARD
GS14-K3162-1	14-15 GMC 1500 BS BUMPER W/ PRE-RUNNER GUARD
NT04-K1760-1	04-14 NISSAN TITAN BS BUMPER W/ FULL GUARD
NT04-K1761-1	04-14 NISSAN TITAN BS BUMPER W/ NO GUARD
NT04-K1762-1	04-14 NISSAN TITAN BS BUMPER W/ PRE-RUNNER GUARD
TT07-K1860-1	07-13 TOYOTA TUNDRA BS BUMPER W/ FULL GUARD
TT07-K1861-1	07-13 TOYOTA TUNDRA BS BUMPER W/ NO GUARD
TT07-K1862-1	07-13 TOYOTA TUNDRA BS BUMPER W/ PRE-RUNNER GUARD
TT14-K2860-1	14-15 TOYOTA TUNDRA BS BUMPER W/ FULL GUARD
TT14-K2861-1	14-15 TOYOTA TUNDRA BS BUMPER W/ NO GUARD
TT14-K2862-1	14-15 TOYOTA TUNDRA BS BUMPER W/ PRE-RUNNER GUARD

REAR BUMPERS

PART NUMBER	DESCRIPTION
CH99-T1250-1	03-07 CLASSIC CHEVY / GMC HD 2500 - 3500 BS REAR BUMPER
CH08-T1450-1	07.5-10 CHEVY / GMC HD 2500 - 3500 BS REAR BUMPER
CH11-T2150-1	11-14 CHEVY / GMC HD 2500 - 3500 BS REAR BUMPER
CH14-T3050-1	15-16 CHEVY / GMC HD 2500 - 3500 BS REAR BUMPER
CS07-T1850-1	07-13 CHEVY / GMC 1500 BS REAR BUMPER
CS14-T3150-1	14-15 CHEVY / GMC 1500 BS REAR BUMPER
DR94-T1650-1	94-02 DODGE HD 2500 - 3500 BS REAR BUMPER
DR03-T1050-1	03-09 DODGE HD 2500 - 3500 BS REAR BUMPER
DR10-T2950-1	10-15 DODGE HD 2500 - 3500 BS REAR BUMPER
FS08-T1350-1	99-15 FORD SD F250 - F350 BS REAR BUMPER
FF09-T1750-1	09-14 FORD F150 BS REAR BUMPER
FF15-T3250-1	15-16 FORD F150 BS REAR BUMPER
NT04-T1950-1	04-14 NISSAN TITAN BS REAR BUMPER
TT07-T1550-1	07-13 TOYOTA TUNDRA BS REAR BUMPER
TT14-T2850-1	14-15 TOYOTA TUNDRA BS REAR BUMPER

FULL SIZE REPLACEMENT BUMPERS

PART NUMBER	DESCRIPTION	(ALL PARTS ARE AVAILABLE BARE STEEL - CH05-S1360-B)
CH05-S1360-1	03-07 CLASSIC CHEVY HD 2500 - 3500 BS BUMPER W/ FULL GUARD	
CH05-S1361-1	03-07 CLASSIC CHEVY HD 2500 - 3500 BS BUMPER W/ NO GUARD	
CH05-S1362-1	03-07 CLASSIC CHEVY HD 2500 - 3500 BS BUMPER W/ PRE-RUNNER GUARD	
CH08-S2060-1	07.5-10 CHEVY HD 2500 - 3500 BS BUMPER W/ FULL GUARD	
CH08-S2061-1	07.5-10 CHEVY HD 2500 - 3500 BS BUMPER W/ NO GUARD	
CH08-S2062-1	07.5-10 CHEVY HD 2500 - 3500 BS BUMPER W/ PRE-RUNNER GUARD	
CH11-S2760-1	11-14 CHEVY HD 2500 - 3500 BS BUMPER W/ FULL GUARD	
CH11-S2761-1	11-14 CHEVY HD 2500 - 3500 BS BUMPER W/ NO GUARD	
CH11-S2762-1	11-14 CHEVY HD 2500 - 3500 BS BUMPER W/ PRE-RUNNER GUARD	
CH14-S3060-1	15-16 CHEVY HD 2500 - 3500 BS BUMPER W/ FULL GUARD	
CH14-S3061-1	15-16 CHEVY HD 2500 - 3500 BS BUMPER W/ NO GUARD	
CH14-S3062-1	15-16 CHEVY HD 2500 - 3500 BS BUMPER W/ PRE-RUNNER GUARD	
DR94-S1560-1	94-02 DODGE HD 2500 - 5500 BS BUMPER W/ FULL GUARD	
DR94-S1561-1	94-02 DODGE HD 2500 - 5500 BS BUMPER W/ NO GUARD	
DR94-S1562-1	94-02 DODGE HD 2500 - 5500 BS BUMPER W/ PRE-RUNNER GUARD	
DR03-S1060-1	03-05 DODGE HD 2500 - 5500 BS BUMPER W/ FULL GUARD	
DR03-S1061-1	03-05 DODGE HD 2500 - 5500 BS BUMPER W/ NO GUARD	
DR03-S1062-1	03-05 DODGE HD 2500 - 5500 BS BUMPER W/ PRE-RUNNER GUARD	
DR06-S1160-1	06-09 DODGE HD 2500 - 5500 BS BUMPER W/ FULL GUARD	
DR06-S1161-1	06-09 DODGE HD 2500 - 5500 BS BUMPER W/ NO GUARD	
DR06-S1162-1	06-09 DODGE HD 2500 - 5500 BS BUMPER W/ PRE-RUNNER GUARD	
DR10-S2960-1	10-15 DODGE HD 2500 - 5500 BS BUMPER W/ FULL GUARD	
DR10-S2961-1	10-15 DODGE HD 2500 - 5500 BS BUMPER W/ NO GUARD	
DR10-S2962-1	10-15 DODGE HD 2500 - 5500 BS BUMPER W/ PRE-RUNNER GUARD	
FS99-S1660-1	99-04 FORD SD F250 - F350 BS BUMPER W/ FULL GUARD	
FS99-S1661-1	99-04 FORD SD F250 - F350 BS BUMPER W/ NO GUARD	
FS99-S1662-1	99-04 FORD SD F250 - F350 BS BUMPER W/ PRE-RUNNER GUARD	
FS05-S1260-1	05-07 FORD SD F250 - F350 BS BUMPER W/ FULL GUARD	
FS05-S1261-1	05-07 FORD SD F250 - F350 BS BUMPER W/ NO GUARD	
FS05-S1262-1	05-07 FORD SD F250 - F350 BS BUMPER W/ PRE-RUNNER GUARD	
FS08-S1960-1	08-10 FORD SD F250 - F350 BS BUMPER W/ FULL GUARD	
FS08-S1961-1	08-10 FORD SD F250 - F350 BS BUMPER W/ NO GUARD	
FS08-S1962-1	08-10 FORD SD F250 - F350 BS BUMPER W/ PRE-RUNNER GUARD	
FS11-S2560-1	11-15 FORD SD F250 - F350 BS BUMPER W/ FULL GUARD	
FS11-S2561-1	11-15 FORD SD F250 - F350 BS BUMPER W/ NO GUARD	
FS11-S2562-1	11-15 FORD SD F250 - F350 BS BUMPER W/ PRE-RUNNER GUARD	
GM08-S2160-1	07.5-10 GMC HD 2500 - 3500 BS BUMPER W/ FULL GUARD	
GM08-S2161-1	07.5-10 GMC HD 2500 - 3500 BS BUMPER W/ NO GUARD	
GM08-S2162-1	07.5-10 GMC HD 2500 - 3500 BS BUMPER W/ PRE-RUNNER GUARD	
GM11-S2860-1	11-14 GMC HD 2500 - 3500 BS BUMPER W/ FULL GUARD	
GM11-S2861-1	11-14 GMC HD 2500 - 3500 BS BUMPER W/ NO GUARD	
GM11-S2862-1	11-14 GMC HD 2500 - 3500 BS BUMPER W/ PRE-RUNNER GUARD	
GM14-S3160-1	15-16 GMC HD 2500 - 3500 BS BUMPER W/ FULL GUARD	
GM14-S3161-1	15-16 GMC HD 2500 - 3500 BS BUMPER W/ NO GUARD	
GM14-S3162-1	15-16 GMC HD 2500 - 3500 BS BUMPER W/ PRE-RUNNER GUARD	

ACCESSORIES

PART NUMBER	DESCRIPTION
M1650-1	RANCH WINCH TRAY (FITS ALL FULL SIZE BS FRONT BUMPERS)
K1200-1	1/2-TON RANCH WINCH TRAY (FITS ALL BS HALF TON BUMPERS)
M1750-1	RANCH 2" RECEIVER (FITS ALL FULL SIZE BS FRONT BUMPERS)
M1850-1	RANCH D-RING MOUNTS (FITS ALL BS FRONT BUMPERS) QUANTITY 2
Z1350	BS BUMPER STAND (REQUIRES PURCHASE OF BS FRONT BUMPER)
Z1350R	BS REAR BUMPER STAND (REQUIRES PURCHASE OF BS REAR BUMPER)
BSPOP	BLACK STEEL POP
SGAIR-1	BLACK STEEL HI-FLOW LOWER GUARD
SLITE-1	BLACK STEEL LIGHT LOWER GUARD



FS08-W1350-1 // 99-15 FORD SD REAR BUMPER



DR09-W2950-1 // 10-15 DODGE HD REAR BUMPER



BLACK STEEL

CS14-T3150-1 // 14-15 CHEVY/GMC 1500 BS REAR BUMPER



CH14-U3050-1 // 15-16 CHEVY/GMC HD ELITE REAR BUMPER

BLACK STEEL
ELITE

