

Thank you for purchasing KC HiLiTES products; your satisfaction is very important to us.

Parts Included:

(2) Raptor Cowl Mounts (Passenger + Driver Side)

Tools Needed:

10mm Socket



1. Raise the hood and locate the (2) 10mm hinge bolts that attach to the top of the fender. Before removing the (2) bolts, please use a scribe or marker to notate the exact hinge location to ensure proper alignment when re-installing the bolts with the brackets. After marking, remove the (2) hinge bolts from one side of the truck.



2. Feed the Cowl Mount Bracket in-between the hood/body of the truck and place on top of the hinge. Begin tightening the bolts, align the hinge to your markings and then fully tighten.

3. Repeat steps 1-2 for the other side of vehicle. Mount your KC Lights of choice.