

2007 - 2014 FORD Edge (Fits All Models)

STEP 1

<u>Remove Floor Mat from box and allow it to lay out in a warm area</u>. This allows the mat to regain it's custom shape after being rolled up for shipping.



