



MOUNTING BRACKET, ALTERNATOR

P/N 63815

INSTALLATION INSTRUCTIONS

This kit comes complete with enough Spacers and Hardware to perform several different installations of the alternator. This kit will work with different combinations mounted to the front of the motor. After determining the approximate position of your alternator (and the drive pulley or gear):

- 1. Place all pulleys and spacers in order starting from the longest to the shortest. This will help when trying to find a slightly longer or shorter spacer or bolt.**
- 2. Find the right spacer or combination of spacers to give you the height that you are looking for.**
- 3. Lay the bolts out in the same way you did with the Spacers in step (1).**
- 4. Select the hardware needed and torque the bolts to factory specifications.**