



INSTALLATION INSTRUCTIONS

ONKI ONE-PIECE BRUSH GUARD – PART # 486342, # 486343
03-06 HUMMER H2

Installation of [Brush Guard](#)

1. Remove plastic bumper filler.



2. Remove 4 factory bolts, 2 on each side.



3. Install brush guard with the 4 factory bolts.



4. Reinstall plastic bumper filler.