

FLEXIBLE LED UNDERCAR KIT

INSTALLATION INSTRUCTIONS



PLEASE READ ALL INSTRUCTIONS CAREFULLY
BEFORE BEGINNING INSTALLATION

1. Disconnect the car battery before installing your kit.
2. The Flexible LED Strips should be placed under the chassis of your vehicle so that they are not directly visible. Visible tubes are prohibited by law in most cities. Choose a location for each tube that is away from all fuel lines, exhaust pipes, moving parts, areas of extreme heat, or pinch and lift points.
3. Using the supplied clamps, fasten the tubes under your vehicle with the included self-tapping screws. The clamps will fit over the top and bottom of the Flexible LED Strip and will be secure when the screw is tightened. While installing the side tubes, make sure that the wire on each tube faces the front of the vehicle. Make sure the strips are secure, but do not over tighten.
4. Your kit includes a Splitter Box that all of your tubes will be wired into. Mount it in the engine compartment on a flat area that will not get wet. Route the wires from each tube into the Splitter Box and use a small flathead screwdriver to secure them into the box. The Red wires should go into the + input on the box and the Black wires should go into the – input on the box.
5. Mount the included switch inside your vehicle to turn the kit on and off. Connect the Red and Black wires on the switch directly to the car battery or to another 12V power source inside the vehicle. The 2nd Red wire on the switch should run to the Splitter Box to power the tubes. The black wire on the splitter box should be connected to the – side of the battery or grounded to another point on the vehicle.
6. If you would like to fill your wheel wells with a matching glow, you can add the PlasmaGlow Flexible LED Wheel Well Kit to your vehicle also.
7. Installation is complete.

Shop for other accessory lighting on our website.