

2007-2014+ Jeep Wrangler 20" [Light Bar](#) Hood Mount Brackets

Please read all instructions before installation and to verify that all parts are included.

Kit For Putco 10020 Light Bar Only

KIT CONTENTS:	
Description	Qty.
Light Bar Driver Side Bracket	1
Light Bar Passenger Side Bracket	1
M8 x 20mm Bolts 5mm Hex	4

Tools Needed:

- T 40 Torx Bit
- 5mm Hex Bit
- Ratchet

Bracket Installation

1. Remove bracket kit from packaging. Check to see if all parts from above kit contents table are included.
2. Remove Bolts shown in **Figure 1**. Use **T40** Torx Bit to remove.
3. Install brackets using supplied hardware. Tighten Down Using **5mm Hex Bit**. Passenger side orientation is shown in **Figure 2**.
4. Mount 20" light bar between brackets. (These brackets are designed for Putco 10020 Light Bar, Refer to Putco Light Bar Installation Instructions for mounting and wiring light bar.)



Figure 1



Figure 2