

SGG60VS

2008-09 G8 304 [Polished Stainless Axle-back w/ Violator Muffler](#)



Begin by placing the vehicle on a lift or four jack stands at maximum height. This will aid in an easier installation.

1. Unbolt the factory axle-back mufflers from the stock flange using a 13mm wrench. Soaking your factory mounting points with penetrating oil will allow for easier removal. Next, slide the mufflers towards the front of the vehicle to remove them from the factory hangers.
2. It's time to install your new axle-back system. Simply slide the hangers on the new axle-back into the factory mounting point, making sure the gaskets are still in place. Next, bolt the flanges back in place, don't forget the gasket.

Now it's time to fire up that muscle car and enjoy your new Pypes Performance Exhaust.

