

This document contains the recommended bolt lengths required for installation of the Domestique or Sidearm to a top of car factory rack. Please note that all bolts are included in the box with the product (*no Xadapt kits are necessary*).



← minimum bar spread required: 12" →

### Domestique™

Premium direct-to-factory crossbar fork-mounted carrier delivers maximum stability and protection through its oversized aluminum tray and precision skewer.

 **513** | Carries 1 bike

- ▣ Aerodynamic durable aluminum construction provides stable mounting platform
- ▣ Easy-to-use lockable stainless steel skewer with over-sized lever makes for secure loading and unloading
- ▣ Adjustable wheel strap with integrated wheel stabilizer for secure bike transport
- ▣ Versatile design compatible with 9mm fork mount bikes and most disc brakes
- ▣ Fits bike wheelbases up to 48" and tire widths up to 2.3"
- ▣ Fits Thule rack systems, round bars and most factory racks



← minimum bar spread required: 18" →

### Sidearm™

Get maximum frame protection with this upright roof-mounted bike carrier as it makes contact with the wheel only.

 **594XT** | Carries 1 bike

- ▣ SecureHook™ holds the bike by grabbing the front wheel – no frame contact is made
- ▣ Ratcheting wheel strap quickly secures back wheel to tray
- ▣ Versatile design accommodates bikes with disc brakes, thru-axes and other non-traditional frame designs
- ▣ Corrosion resistant double-wall aluminum tray provides maximum strength and rigidity
- ▣ Fits 20" to 29" wheel diameter bicycles with tires up to 2.6" wide
- ▣ 1 One-Key™ lock cylinder (sold separately) locks the bike to carrier and carrier to rack
- ▣ Fits Thule rack systems, round bars and most factory racks

VEHICLE MAKE, MODEL AND YEAR	513 DOMESTIQUE		594XT SIDEARM		
	SHORT	LONG	55mm	65mm	80mm

## THULE

STEEL (LB) BARS		✓		✓	
RAPID AERO (RB) BARS		✓			✓
XSPORTER BARS		✓			✓
PRO BARS			✓		✓

## YAKIMA

LOAD BAR		✓		✓	
----------	--	---	--	---	--

## ACURA

MDX	'07-10	✓		✓	
RDX	'07-10	✓		✓	

## AUDI

A4 (Avant) Wagon	'09-10	✓		✓	
A4 (Avant) Wagon	'02-08	✓		✓	
A6 Wagon	'06-10	✓		✓	
Q5	'09-10	✓			✓
Q7	'07-10	✓			✓
S4 Wagon	'01-08	✓		✓	

## BUICK

Enclave	'08-10	✓			✓
Ranier	'04-07	✓		✓	
Rendezvous	'02-07	✓			✓

## CADILLAC

Escalade	'07-10	✓		✓	
	'01-06	✓		✓	
	'99-00	✓		✓	
Escalade	'07-10	✓		✓	
	'03-06	✓		✓	
Escalade EXT Pickup	'02-10	✓		✓	

## CHEVROLET

Astro Van	'94-05	✓		✓	
Avalanche	'07-10	✓			✓
	'02-06	✓			✓
Blazer 2DR	'95-05	✓		✓	
Blazer 4DR	'95-04	✓		✓	
Equinox	'10	✓			✓
HHR	'05-09	✓			✓
	'06-10	✓			✓
	'07-10	✓		✓	
Suburban	'00-06	✓		✓	
	'92-99	✓		✓	
	'07-10	✓		✓	
Suburban Z71	'07-10	✓		✓	
	'01-06	✓		✓	
Tahoe 2DR	'95-99	✓		✓	
Tahoe 4DR	'07-10	✓		✓	
	'00-06	✓		✓	
	'95-99	✓		✓	
Tahoe Z71	'01-06	✓		✓	
Tracker 4DR	'02-04	✓			✓
Traverse	'09-10	✓			✓
Venture	'97-04	✓		✓	

VEHICLE MAKE, MODEL AND YEAR		513 DOMESTIQUE		594XT SIDEARM		
		SHORT	LONG	55mm	65mm	80mm

## CHRYSLER

Pacifica	'04-08	✓		✓	
PT Cruiser	'01-10	✓			✓
Town & Country	'08-10	✓		✓	
	'01-07	✓		✓	
	'96-00	✓		✓	
Voyager / Grand Voyager	'01-03	✓		✓	

## DODGE

Caliber / SRT4	'07-10	✓		✓	
Caravan / Grand Caravan	'08-10	✓		✓	
	'01-07	✓		✓	
	'96-00	✓		✓	
Durango / Durango Sport	'98-03	✓		✓	
Journey	'08-10	✓		✓	
Nitro	'07-10	✓		✓	

## FORD

Edge / Edge Sport	'07-10	✓		✓	
Escape	'07-10	✓		✓	
	'01-07	✓		✓	
	'05-10	✓			✓
Expedition	'97-04	✓			✓
Expedition EL	'07-10	✓			✓
	'97-04	✓			✓
Explorer 2DR	'96-00	✓			✓
Explorer 4DR	'05-10	✓			✓
	'02-04	✓			✓
	'96-01	✓			✓
Explorer Sport 2DR	'91-95	✓			✓
	'01-03	✓			✓
	'01-03	✓			✓
Explorer Sport Trac	'01-03	✓			✓
	'07-10	✓			✓
Flex	'01-05	✓			✓
Flex	'08-10	✓			✓
Freestar	'04-07	✓		✓	
Windstar	'98-03	✓		✓	

## GMC

Acadia	'07-10	✓			✓
Denali	'01-04	✓			✓
	'98-00	✓			✓
Denali XL	'00-04	✓			✓
Envoy	'98-01	✓		✓	
Jimmy 2DR	'95-01	✓		✓	
Jimmy 4DR	'95-01	✓		✓	
Safari Van	'94-05	✓		✓	
	'90-93	✓		✓	
Suburban	'92-99	✓		✓	
Terrain	'10	✓		✓	
Yukon 2DR	'92-99	✓		✓	
Yukon 4DR (Except Denali Models)	'07-10	✓		✓	
	'00-06	✓		✓	
Yukon XL	'95-99	✓		✓	
	'07-10	✓		✓	
Yukon XL	'00-06	✓		✓	
Yukon Denali	'07-10	✓		✓	
Yukon Denali XL	'07-10	✓		✓	

# DOMESTIQUE/SIDEARM HARDWARE FIT GUIDE



VEHICLE MAKE, MODEL AND YEAR	513 DOMESTIQUE		594XT SIDEARM		
	SHORT	LONG	55mm	65mm	80mm

## HONDA

Crosstour	'10	✓		✓	
CRV	'07-10	✓		✓	
	'02-06	✓		✓	
Element	'03-10	✓	✓		
Odyssey	'05-10	✓		✓	
	'01-04	✓		✓	
Passport	'98-02	✓	✓		
Pilot	'09-10	✓	✓		
	'03-08	✓		✓	
Ridgeline	'06-10	✓		✓	

## HUMMER

H3	'05-10	✓		✓	
H3T	'09-10	✓		✓	

## HYUNDAI

Entourage	'07-10	✓		✓	
Santa Fe	'07-10	✓		✓	
	'01-06	✓		✓	
Tucson	'05-09		✓		✓

## INFINITI

EX 35	'08-10	✓		✓	
FX 35	'03-10	✓		✓	
FX 45	'03-08	✓		✓	
FX 50	'09-10	✓		✓	
QX4 s	'97-03	✓		✓	
QX56	'08-10	✓		✓	
	'04-07	✓		✓	

## ISUZU

Ascender S	'03-10	✓		✓	
Rodeo	'98-04	✓		✓	

## JEEP

Commander w/ Standard Crossbars	'06-10	✓		✓	
Grand Cherokee	'05-10	✓		✓	
	'99-04	✓		✓	
	'93-98	✓		✓	
Liberty	'02-10	✓		✓	
Patriot	'07-10	✓		✓	

## KIA

Borrego	'09-10	✓		✓	
Carens	'07-10	✓		✓	
Rondo	'07-10	✓		✓	
Sedona	'06-10	✓		✓	
	'02-05	✓		✓	
Sorento	'11	✓		✓	
	'03-09	✓		✓	
Soul	'10	✓		✓	

## LAND ROVER

LR3	'05-09		✓		✓
LR4	'10		✓		✓
Range Rover	'03-10		✓		✓
	'98-02		✓		✓

VEHICLE MAKE, MODEL AND YEAR	513 DOMESTIQUE		594XT SIDEARM		
	SHORT	LONG	55mm	65mm	80mm

## LEXUS

GX 470	'03-10	✓		✓	
LX 470	'99-07	✓		✓	
LX 570	'08-10	✓		✓	
RX 330	'04-06	✓		✓	
RX 350	'05-10	✓		✓	
RX 400H	'05-10	✓		✓	
RX 450H	'10	✓		✓	

## LINCOLN

Aviator	'03-05	✓		✓	
MKX	'07-10	✓		✓	
Navigator	'98-10	✓		✓	

## MAZDA

CX-9	'07-10	✓		✓	
MPV	'00-06	✓		✓	
Protégé 5 Wagon	'02-03	✓		✓	
Tribute	'08-10	✓		✓	
	'01-06	✓		✓	

## MERCURY

Mariner	'05-10	✓		✓	
Monterey	'04-07	✓		✓	
Mountaineer	'05-10	✓		✓	
	'02-04	✓		✓	
	'96-01	✓		✓	
Sable Wagon	'96-05	✓		✓	
Villager	'99-02	✓		✓	
	'93-98	✓		✓	

## MINI

Clubman	'08-10	✓		✓	
---------	--------	---	--	---	--

## MITSUBISHI

Endeavor	'04-10	✓		✓	
Montero Sport	'99-00	✓		✓	
	'97-98	✓		✓	

## NISSAN

Armada	'08-10		✓		✓
	'04-07		✓		✓
Frontier 4DR Crew Cab	'05-10	✓		✓	
	'00-04	✓		✓	
Murano	'03-10	✓		✓	
Pathfinder	'05-10	✓	✓		✓
	'02-04	✓		✓	
Pathfinder 2DR	'87-90	✓		✓	
Pathfinder 4DR	'96-01	✓		✓	
Quest	'04-10	✓		✓	
	'99-02	✓		✓	
Rogue	'08-10	✓		✓	
Xterra	'09-10		✓		✓
	'00-04		✓		✓

## OLDSMOBILE

Bravada	'02-04	✓		✓	
	'96-01	✓		✓	
	'91-94	✓		✓	

VEHICLE MAKE, MODEL AND YEAR	513 DOMESTIQUE		594XT SIDEARM		
	SHORT	LONG	55mm	65mm	80mm

## OLDSMOBILE continued

Silhouette	'97-04	✓		✓		
------------	--------	---	--	---	--	--

## PLYMOUTH

Voyager/Grand Voyager	'96-00	✓		✓		
-----------------------	--------	---	--	---	--	--

## PONTIAC

Aztec	'01-05	✓		✓		
Montana	'99-05	✓			✓	
Torrent	'06-09	✓		✓		
Trans Sport	'97-98	✓		✓		
Vibe	'09-10	✓		✓		
	'03-08	✓		✓		

## SATURN

Outlook	'07-10	✓			✓	
Vue	'02-05	✓			✓	

## SUBARU

Baja 4DR	'03-07	✓		✓		
Forester	'09-10	✓			✓	
	'03-08	✓			✓	
	'98-02	✓			✓	
Impreza / WRX / STI Wagon	'08-10	✓			✓	
	'02-07	✓			✓	
Legacy Wagon	'00-04	✓			✓	
	'95-99	✓			✓	
Legacy Outback	'96-99	✓			✓	
Outback Sport/WRX/STI Wagon	'08-10	✓			✓	
	'02-07	✓			✓	
Outback Wagon	'10	✓			✓	
	'08-09	✓			✓	
	'05-07	✓			✓	
	'00-04	✓			✓	
Outback Sport	'02-10	✓		✓		
Tribeca	'06-07	✓			✓	

## SUZUKI

Grand Vitara	'06-10	✓		✓		
XL-7	'07-09	✓		✓		

VEHICLE MAKE, MODEL AND YEAR	513 DOMESTIQUE		594XT SIDEARM		
	SHORT	LONG	55mm	65mm	80mm

## TOYOTA

4 Runner	'10	✓		✓		
	'03-09	✓		✓		
4 Runner 2DR	'90-95	✓		✓		
4 Runner 4DR	'90-02	✓		✓		
Highlander	'10	✓			✓	
	'08-09	✓			✓	
	'01-07	✓			✓	
Land Cruiser	'98-10	✓			✓	
Matrix	'09-10	✓		✓		
	'03-08	✓		✓		
RAV4	'07-10	✓			✓	
	'01-06	✓			✓	
Sequoia	'08-10	✓			✓	
	'01-07	✓			✓	
Sienna	'11	✓		✓		
	'10	✓		✓		
	'04-09	✓		✓		
	'98-03	✓		✓		
Venza	'09-10	✓		✓		

## VOLKSWAGEN

Golf Wagon (Canada Only)	'10	✓		✓		
Jetta SportWagen	'09-10	✓		✓		
Routan	'09-10	✓		✓		
Tiguan	'08-10	✓			✓	
Touareg (aka Touareg 2)	'08-10		✓			✓
Touareg	'04-07		✓			✓

## VOLVO

V70	'98-10	✓			✓	
V70 XC	'01-10	✓			✓	
	'98-00	✓			✓	
XC70	'01-10	✓			✓	
XC90	'03-10	✓			✓	