

TBR

2017 INDIAN SCOUT

Comp-S 2-1 Part # 005-4610199



BILL OF MATERIALS



1	Front Header	005-46101H1
1	Rear Header	005-46101HR
1	Slip-On Muffler	005-46101S
2	Hose Clamp	005-HC-64024
1	Muffler Bracket	005-461-B
2	Flange Bolt	005-FB1634
2	Clip Nut	005-10-516CN
2	O2 Sensor Kit	005-92-22KIT
2	Spring 45mm	005-S45
1	Spring Puller	005-SP
1	Sticker Kit	015-10212
1	Heat Shield	--

INSTALLATION INSTRUCTIONS

1. Make sure bike is completely cool before starting the installation. Make sure the bike is secure on the sidestand or ideally a service lift.
2. Remove OEM mufflers from the motorcycle. **(Reference image 1)**
3. Remove OEM headers front and rear from the motorcycle. **(Reference image 2)**



4. Remove OEM bracket from the motorcycle. **(Reference image 3)**
5. Install the supplied 12mm O2 Sensor adapters on the TBR Headers.
6. Loosely install the front and rear headers using the OEM flange nuts. It may help to thread in the O2 Sensors prior to installation. **(Reference image 4)**




7. *Note, it may be helpful to use a "Flex" or "Swivel" socket with extension to reach the flange nuts. **(Reference image 5)**
8. Attach the 2 supplied clip nuts to the back of the bracket welded to the muffler. **(Reference image 6)**



IMPORTANT - PLEASE READ CAREFULLY: We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Also, make sure the bike is secure on a center stand or ideally a service lift during installation. Be sure to save all stock components for possible use later.

WARRANTY: Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.

9. Fit the muffler to the headers. It may help to have a friend assist and tap the muffler with a rubber mallet to help secure it onto the headers all of the way. **(Reference image 7)**
10. Loosely install the supplied TBR bracket onto the swingarm pivot bolt and attach it to the welded bracket on the muffler using the supplied flange bolts.
11. Install the supplied springs attaching the headers to the muffler assembly.
12. Ensure the exhaust has clearance around the engine before tightening the flanges and muffler bracket down. **(Reference image 8)**



13. Install TBR Heat Shields if desired using the supplied hose clamps.
14. Double check your work and make sure everything is tight.
15. Before you run the bike, clean off all fingerprints and dirt, as any oily residue will etch the metal and become somewhat permanent when the system gets hot. Run the bike and enjoy. It is normal for some white smoke to appear the first time you start the bike. This is packing/manufacturing oil from inside the pipe burning off. Check for gaps or leaks. If you find a leak, a little high temperature silicon sealant should fix it. After 50 to 100 miles, recheck all fasteners for tightness.

Care & Cleaning

Keep system free of dirt and moisture. Store in a cool, dry place. Make sure vehicle is completely cool before maintenance.

Stainless Header System: Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Titanium Header System: Polished titanium pipes will experience color shift ranging from deep blue/purple through amber after a few heat cycles. This is a normal characteristic of high quality titanium. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Polished Aluminum Canisters: Use an aluminum or mag wheel polish to restore the bright finish to factory spec.

Brushed Aluminum Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Carbon Fiber Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.


Titanium Mufflers: For cleaning use a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve.

TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Repack all road canisters at the first signs of packing material deterioration. Part #005-10038

Repack all offroad canisters after every 10 hours of use. Part #005-10038MX

NEVER dyno test your bike with carbon fiber or titanium canisters installed - the intense heat and lack of cooling air can quickly burn through the canister material. Two Brothers Racing does not provide a warranty for burned canisters.



BILL OF MATERIALS

1	Front Header	005-46101H1
1	Rear Header	005-46101HR
1	Slip-On Muffler	005-46101S
2	Hose Clamp	005-HC-64024
1	Muffler Bracket	005-461-B
2	Flange Bolt	005-FB1634
2	Clip Nut	005-10-516CN
2	O2 Sensor Kit	005-92-22KIT
2	Spring 45mm	005-S45
1	Spring Puller	005-SP
1	Sticker Kit	015-10212
1	Heat Shield	--