

INSTRUCTIONS

APPLICATION: 2001-04 FORD EXPLORER SPORT 2DR 2/4WD 2001-05 FORD EXPLORER SPORT TRAC 4DR 2/4WD


AUTOMOTIVE PRODUCTS, INC.


SAFARI BAR ASSEMBLY


30-0000 30-0005

MOUNT KIT

30-1145







ITEM	QTY	CONTENTS	TOOLS
1 2,3 4 5 6 7 8	1 2 2 4 10 6 4	SAFARI BAR ASSEMBLY (PURCHASED SEPARATELY) BRACKET, PASSENGER (2) AND DRIVER (3) 1/2-13 X 2.00" HEX HEAD BOLT 1/2-13 X 1.25" HEX HEAD BOLT 1/2" FLAT WASHER 1/2" LOCK WASHER 1/2-13 HEX NUT	3/4" SOCKET 8MM SOCKET 10MM SOCKET 15MM SOCKET RATCHET TORQUE WRENCH

- STEP 1. Remove the contents from box and check for damage. Verify all parts are present. Read instructions completely before beginning.
- STEP 2. Remove four 8mm bolts and three 6mm bolts that secure the lower shroud cover located behind bumper.
- STEP 3. Loosen front and rear tow hook bolts.

 NOTE: Vehicles without tow hooks, attach brackets to frame using 1/2"fasteners as shown. Install bolts through existing holes in L bracket on side of frame. SEE FIGURE 1.
- STEP 4. Attach brackets between tow hooks and vehicle frame. Leave loose.
- STEP 5. Attach Safari Bar to mount brackets using 1/2" fasteners. Level and adjust Safari as desired and tighten all fasteners. Recommended torque values are 64 Ft. Lbs. for 1/2" fasteners and 50 Ft. Lbs. for tow hook bolts.
- STEP 6. Reinstall lower shroud cover. Torque 8mm fasteners to 26 FT. LBS. and 6mm fasteners to 11 FT. LBS.




FIGURE 1 PASSENGER SIDE SHOWN, DRIVER SIDE OPPOSITE

