

# SNOWMOBILE STORAGE COVER



Figure 1

## CLEANING

Clean your cover with a soft brush and some lukewarm water. It may also be machine washed in COLD water. DO NOT USE SOAP, as it may remove the protective coatings added by the factory. Line dry or machine dry on air or delicate.

## STORAGE

A handy storage sack is attached to the rear of your cover. Be sure the cover is completely dry before you store it in the sack for an extended period.

## WARNING

**Do not use while transporting your snowmobile — the cover could blow off and cause injury to others.**

1. Cover any sharp points (such as a windshield corner) with cloth or a sponge to avoid stressing your cover when it is stretched tight across your snowmobile.
2. Find the white label with arrows sewn in the hem of the cover—this is the front of your cover. Now stretch the cover down over your snowmobile.
3. Locate the strap [A] in the middle of your cover (Fig. 1). From where the strap attaches to the cover, run the strap end with the male buckle under your snowmobile and then back up to clip it into the female buckle. Tighten the strap so that is snug, but not cinched completely tight.
4. Run the forward strap [B] under your snowmobile behind the ski struts and connect it into the buckle on the opposite side.
5. Run the rear strap [C] under the tail of your snowmobile into the buckle on the opposite side.

Tighten all the straps as necessary for a tight fit on your snowmobile.