

iSimple[®] MediaWire[™]

Owner's Manual

CAR STEREO OR
A/V SYSTEM
INTEGRATION FOR YOUR iPod

MAKE THE CONNECTION ►

to your

iPod

to your

iPhone



• connector for iPod



• RCA audio/video output

1. Introduction

Thank you for purchasing the iSimple® MediaWire™. This product is designed to provide endless hours of listening and viewing pleasure from your factory or aftermarket entertainment system. To ensure optimal performance of the MediaWire™ we recommend that you read this entire manual before beginning the installation of this product. The MediaWire™ provides connectivity between your iPod/iPhone and any audio or audio/video source that accepts RCA connections. The audio from the attached device will be passed through the cable into the radio's auxiliary Audio or A/V input. Note: many factory radios require an auxiliary input device to accept an RCA connection. For video output, an iPod/iPhone with video capability is required.

The MediaWire™ will also charge your iPod/iPhone while connected.

2. Precautions

PREVENTING DAMAGE TO YOUR VEHICLE OR MEDIA PLAYER
Installation of this product requires you to make wiring connections. To eliminate the risk of an electrical short, we recommend disconnecting the vehicle's battery prior to installation. If you do not feel comfortable making these connections, we suggest you seek professional installation. We recommend that the iPod/iPhone be disconnected from the cable when the vehicle is not in use.

3. Installation

1. Using a voltmeter identify a 12V+ wire and a ground wire
2. Connect the red wire on the MediaWire™ to the 12V+ constant power wire (or you can connect the MediaWire™ red wire to a switched accessory wire to provide battery charging only when the vehicle is running).
3. Connect the black wire on the MediaWire™ to ground. Depending on the vehicle this may be a wire or the chassis.
4. Plug the male RCA connector ends of the MediaWire™ into the receivers auxiliary audio or A/V input.
5. Choose a convenient mounting location for your iPod, or iPhone. This is typically a glove box, center console or mounting cradle.
6. Run the docking cable and RCA connectors to the desired mounting location. Use caution to not cut, pinch or crimp the cable during this step.
7. Securely install the cable in a location free from heat, humidity, moving parts, or sharp metal edges. We recommend securing the MediaWire™ to a suitable location using double sided tape, Velcro™ or zip-ties.

Accessing your auxiliary audio source

Please refer to the owners manual that came with your radio or vehicle for directions on how to access your radio's auxiliary input source.

On some iPod models you will need to enter the settings menu, and select video, select TV out, and set this option to "ASK". When a video is selected to play, the iPod will ask "do you want to enable TV out?" select on, to view video on an external screen using this product.

Some newer iPod / iPhone models do not have this option in the video settings menu. Instead, after connecting your iPod / iPhone to our product, and selecting a video to play, the device will ask you automatically "Display on TV?"

Choose "YES" to watch the video on an external monitor.

4. Troubleshooting

Symptom	Cause	Remedy
iPod/iPhone is not charging	Fuse is blown	Check the fuse in the power lead of the MediaWire™. If the fuse is blown, replace with a fuse of the same amperage. If fuse blows again, please call tech support.
iPod/iPhone is not charging and fuse isn't blown	Weak wiring connection	Check the Power (RED) and Ground (BLACK) wires to ensure that they are correctly connected to 12V+ and Ground.
No video	iPod is not set for video out	In settings menu select Video Output ON.
No audio	RCA is not connected	Verify connection of RCA's to Receiver.