30-Day Glo Lantern - Instructions

General Operating Instructions


HIGH, MEDIUM & LOW MODES: Install batteries (see instructions on reverse side). Press power button once for HIGH MODE, twice for MEDIUM MODE, 3 times for LOW MODE and 4 times for OFF.

FLASHING SOS: Press and hold power button for a few seconds until SOS flash begins. This can be done in any mode. Press power button once to reset (this will turn the lantern off).

The power button changes lighting modes as well as powering the lantern on and off



TO CONVERT TO A DOWNLIGHT: Unscrew lens and place aside. Unlatch hook underneath the lantern and move upright. Turn lantern upside down and hang securely.








Battery Changing Instructions

Switch off lantern. Turn base counter clockwise (unscrew) to remove old batteries and properly dispose. Replace with 3 new 1.5V D cell batteries in correct polarity following + and - symbols in the battery compartment. Line-up arrows and notches inside unit, then push down while screwing the base to the body (see diagram). Make sure that the base is tight in order ensure water resistance. Remove batteries when not in use for a long period of time. Do not mix old and new batteries — or rechargeable, standard and alkaline types.



Glow-in-the-Dark Feature

Place lantern in a well-lit area (preferably sunlight) for a minimum of 5 minutes to activate the glow-in-the dark feature on the white rubberized areas of the lantern. 20 minutes of "charging" will allow the unit to glow in the dark for the maximum duration of 2 hours. When the lantern is turned on, the LED will inherently charge the glow-in-the dark surface --particularly the lid area. This feature is especially helpful in instances of a power outage or returning to an unlit area. We recommend that you store your 30-Day Glo Lantern near a window or well-lit spot so it will be charged up and readily visible in the dark.