





# 55587

FORD FIVE HUNDRED  
FORD FREESTYLE

## WIRING LOCATION GUIDE



### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

#### 1. Ford Freestyle

- Open rear hatch. Temporarily remove the rear threshold plate. [A]
- Remove the trunk threshold plate by removing trim panel fasteners on both sides of the trunk and partially remove the felt trunk liner behind the taillights. [B]

#### Ford Five Hundred

- Open trunk. Temporarily remove the rear threshold plate. [A]
- Partially remove the felt trunk liner behind the taillights.
- On the drivers and passenger sides of the vehicle, locate the vehicle's taillight wiring harness. The taillight wiring harness will have a connection point, on both sides, matching the ends of the T-connector. Separate this connector, being careful not to break the locking tabs. All connector surfaces should be clean and free of dirt.
- On the drivers side, insert the T-connector end with the yellow wire between the vehicle wiring connectors and lock into place. Be careful not to damage the locking tabs and be sure that connectors are fully inserted with locking tabs in place. [C]
- Route the T-connector end with the green wire to the passenger's side behind the panels and along the threshold. Repeat step 4 using T-connector containing the green wire.
- Locate a suitable grounding point near the connector. Drill a 3/32" hole and secure the white wire using the eyelet and screw provided or locate an existing ground stud, loosen bolt and place screw eyelet on stud and re-tighten bolt. [D]
- Re-install all items removed during installation being careful not to pinch or cut any wires.

#### WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage to vehicle and/or personal injury.



55587

Looking for dependable trailer hitches and towing? Rely on CURT for quality and long-lasting products.