

# **AFDI-5V**



## **AFDI-5V 12 VOLT TO 5 VOLT CONVERTOR INSTRUCTIONS**

When replacing radios in vehicles with OEM amplifiers, mainly in Ford, Lincoln, and Mercury vehicles, an audible “pop” through the speakers may be heard, especially the subwoofer. The main reason for this “pop” is that the OEM amplifiers do not require 12 volts to turn on but 5 volts.

**Axxess** has developed the AFDI-5V to take a normal 12 volt turn on from the aftermarket radio and drop it down to 5 volts, which the OEM amplifier handles better. A 3 wire hook up makes the **AFDI-5V** very simple to use.

### **Wiring the AFDI-5V:**

1. Connect the **Blue/White** wire to the *aftermarket radio's* amplifier turn on wire.
2. Connect the **Black wire** to chassis ground.
3. Connect the **Blue/Red** wire to the vehicles amplifier turn on wire.