

GM Class-2 data interface 2000-2013

INTERFACE FEATURES

- Provides accessory power (12-volt 10-amp)
- Retains R.A.P. (retained accessory power)
- Can be used in non-amplified, or analog/digital amplified models
- Retains chimes
- Provides NAV outputs (parking brake, reverse, mute, and speed sense)
- Pre-wired ASWC-1 harness included (ASWC-1 sold separately)
- Retains OnStar/OE Bluetooth
- Adjustable volume for chimes and OnStar
- High level speaker input
- USB updatable
- Retains factory rear seat entertainment and satellite radio (in select vehicles)

INTERFACE COMPONENTS

- GMOS-014 interface
- GMOS-014 harness
- 16-pin harness with stripped leads
- 4-pin to 4-pin resistor pad harness

APPLICATIONS

See *inside front cover*

TABLE OF CONTENTS

Connections to be made	3-5
Installing the GMOS-014	6
Initializing the GMOS-014	6
Adjusting the GMOS-014.....	6
Extra Features	7

TOOLS REQUIRED

- Cutting tool • Crimping tool • Tape
- Connectors (example: butt-connectors, bell caps, etc.)

CAUTION! All accessories, switches, climate controls panels, and especially air bag indicator lights must be connected before cycling the ignition. Also, do not remove the factory radio with the key in the on position, or while the vehicle is running.

APPLICATIONS

BUICK

Century	2004-2005
Lacrosse	2005-2009
Rainier	2005-2007
Rainier*	2004-2004
Regal	2004
Rendezvous	2002-2007
Terraza	2005-2007

CADILLAC

Escalade **	2003-2006
Escalade ESV **	2003-2006
Escalade EXT **	2003-2006

CHEVROLET

Avalanche*	2003-2006
Cavalier	2000-2005
Colorado	2004-2012
Corvette	2005-2013
Express	2003-2007
Impala	2000-2005
Kodiak	2003-2009
Malibu	2001-2003
Malibu Classic	2004-2005
Monte Carlo	2000-2005
Silverado Classic*	2007

CHEVROLET (CONT)

Silverado*	2003-2006
SSR*	2003-2006
Suburban*	2003-2006
Tahoe*	2003-2006
Trailblaze	2007-2009
Trailblazer*	2002-2006
Uplander	2005-2008

GMC

Canyon	2004-2012
Envoy	2007-2009
Envoy*	2002-2006
Savanna	2003-2007
Sierra Classic*	2007
Sierra*	2003-2006
TopKick	2005-2009
Yukon*	2003-2006

HUMMER

H2**	2003-2007
H3/H3T	2006-2010

ISUZU

Ascender	2003-2008
H Series	2003-2008
I Series pickups	2006-2008

OLDSMOBILE

Alero	2001-2004
Bravada*	2002-2004
Intrigue	2002

PONTIAC

Aztec	2001-2005
Grand Am	2001-2005
Grand Prix	2004-2008
Montana SV6	2005-2008
Sunfire	2000-2005

SAAB

9-7X	2005-2009
------	-----------

SATURN

Relay	2005-2007
-------	-----------

* These vehicles have a digital amplifier option. Please refer to the Service Parts Identification sticker located in the glove box (for all models except for the Buick Regal which is on the spare tire cover). If the codes UQA or Y91 are present, then you have a digital amplifier.

** These vehicle come standard with a digital amplifier.

CONNECTIONS TO BE MADE

From the 16-pin harness with stripped leads to the aftermarket radio:

- Connect the **Red** wire to the accessory wire.

Note: If installing the ASWC-1, there will be an accessory wire on the 12-pin harness to connect as well.

- Connect the **Orange/White** wire to the illumination wire. (If the aftermarket radio has no illumination wire, tape off the Orange/White wire).
- Connect the **Blue/White** wire to the amp turn on wire (this wire must be connected to hear sound from the factory amplifier).
- Connect the **Brown** wire to the mute wire of the aftermarket radio. If the radio has no mute wire, tape it off and disregard it.
- Connect the **White** wire to the left front positive speaker output.
- Connect the **White/Black** wire to the left front negative speaker output.
- Connect the **Gray** wire to the right front positive speaker output.
- Connect the **Gray/Black** wire to the right front negative speaker output.

Connect the following (4) wires ONLY if your vehicle comes equipped with a digital amplifier:

- Connect the **Green** wire to the left rear positive speaker output.
- Connect the **Green/Black** wire to the left rear negative speaker output.
- Connect the **Purple** wire to the right rear positive speaker output.
- Connect the **Purple/Black** wire to the right rear negative output.

The following (3) wires are for an aftermarket multimedia/navigation radio that provide these wires (if not required, tape them off and disregard them):

- Connect the **Light Green** wire to the parking brake wire (if applicable).
- Connect the **Blue/Pink** wire to the speed sense wire (V.S.S.) (if applicable).

Note: Some models do not have this circuit on the data-bus. Refer to the 12-pin GM harness to the aftermarket radio instructions. If you do not have a wire populated on the factory side, connect this wire instead.

- Connect the **Green/Purple** wire to the reverse wire (if applicable).

From the GMOS-014 harness:

(a) 24-pin GM harness to the aftermarket radio:

- Connect the **Black** wire to the ground wire.
- Connect the **Yellow** wire to the battery wire.

Continue to next page

CONNECTIONS TO BE MADE (CONT)

The following wiring is **ONLY** required if your vehicle **DOES NOT** come equipped with a digital amplifier:

(1) For analog amplified models **ONLY**:

- Connect the **Green** wire to the left rear positive speaker output.
- Connect the **Green/Black** wire to the left rear negative speaker output.
- Connect the **Purple** wire to the right rear positive speaker output.
- Connect the **Purple/Black** wire to the right rear negative output.
- Disconnect the 4-pin harness located between the 24-pin and 22-pin harness, and then connect the supplied 4-pin to 4-pin resistor pad harness.

(2) For non-amplified models **ONLY**:

- Cut the resistors off from the **Green**, **Green/Black**, **Purple**, and **Purple/Black** wires below the heat shrink.
- Connect the **Green** wire to the left rear positive speaker output.
- Connect the **Green/Black** wire to the left rear negative speaker output.
- Connect the **Purple** wire to the right rear positive speaker output.
- Connect the **Purple/Black** wire to the right rear negative output.

Note: The 4-pin to 4-pin resistor pad harness will not be used in this application.

(b) 22-pin harness to the aftermarket radio:

- The **Black/Yellow** wire is used for OnStar level adjustment for models that do not come equipped with steering wheel controls. See OnStar Level Adjustment for further instructions.
- The DIN plug is for use with the optional AX-LCD (sold separately). Refer to EXTRA FEATURES for more information.

(c) 12-pin GM harness to the aftermarket radio:

- If the **Blue/Pink** wire is populated on the factory side, connect this wire to the speed sense wire (V.S.S.) (if applicable).
- Connect the RCA jacks to the audio AUX-IN (if so equipped).

Note: This will only be required if you care to retain the factory rear seat entertainment, or satellite radio.

(d) 12-pin harness to the aftermarket radio:

- This harness is to be used in conjunction with the optional ASWC-1 (not included) to retain steering wheel controls. If the ASWC-1 is not being used, disregard this harness. If it will be used, please refer to the ASWC-1 instructions for radio connections and programming.

Note: Disregard the harness that comes with the ASWC-1.

- Connect the **Red** wire to the accessory wire.

Continued on the next page

CONNECTIONS TO BE MADE (CONT)

The following wire(s) must be cut before programming the ASWC-1:

- * For these vehicles, cut the **White/Green**, **Green/Orange**, and **Yellow/Green** wires.
- ** For these vehicles, cut the **White/Green**, **Pink**, and **Green/Orange** wires.
- *** For these vehicles, cut the **Pink**, and **Green/Orange** wires.

† For these vehicles, cut the **White/Green**, and **Pink** wire.

Δ For these vehicles, cut the **Pink** wire.

BUICK		CHEVROLET (CONT)		GMC		OLDSMOBILE	
Century †	2004-2005	Colorado *	2004-2012	Canyon *	2004-2012	Alero **	2001-2004
LaCrosse †	2005-2009	Corvette ***	2007-2011	Envoy *	2002-2009	Bravada *	2002-2004
Rainer *	2004-2007	Corvette Δ	2012-2013	Sierra *	2003-2006	Intrigue **	2002
Regal †	2004	Impala **	2000-2005	Sierra Classic *	2007		
Rendezvous Δ	2002-2007	Malibu	2001-2003	Yukon *	2003-2006	PONTIAC	
Terraza Δ	2005-2008	Malibu Classic	2004-2005			Aztec **	2001-2005
CADILLAC		Monte Carlo **	2000-2005	HUMMER		Grand Am **	2001-2005
Escalade *	2003-2006	Silverado *	2003-2006	H2 *	2003-2007	Grand Prix **	2004-2008
Escalade ESV *	2003-2006	Silverado Classic *	2007	H3/H3T *	2006-2010	Montana SV6 **	2005-2008
Escalade EXT *	2003-2006	SSR *	2003-2006	ISUZU		Sunfire *	2000-2005
CHEVROLET		Suburban *	2003-2006	Ascender *	2003-2008	SAAB	
Avalanche *	2003-2006	Tahoe *	2003-2006	I-Series pickups *	2006-2008	9-7X *	2005-2009
Cavalier *	2000-2005	Trailblazer *	2002-2009			SATURN	
		Uplander **	2005-2008			Relay **	2005-2007

INSTALLING THE GMOS-014

From the 16-pin harness with stripped leads to the aftermarket radio:

- Connect the 16-pin harness into the interface.
- Connect the 22-pin harness into the interface.
- With the key in the off position, connect the 24-pin and 12-pin GM harnesses into the vehicle.
- With all connections completed, reconnect the negative battery terminal.

Note: If using the ASWC-1, connect it after you initialize and test the GMOS-014, with the key in the off position.

INITIALIZING THE GMOS-014

- Initialize the interface by turning the ignition on for 30 seconds, then turn the ignition back off, then back on again.
- Push the OnStar button; the radio should mute, and you should hear the OnStar voice. Push the OnStar cancel button; the radio should un-mute and play again.

Note: The radio will turn off instead if the mute wire is not connected.

ADJUSTING THE GMOS-014

Chime level adjustment:

- With the vehicle on, turn it off and leave the keys in ignition. Open the driver's door; chimes will be heard.
- Wait 10 seconds, and then with a small screwdriver, turn the potentiometer clockwise to raise the chime level; counterclockwise to lower the chime level.
- When the chime level is at a desired level, remove the keys from the ignition. This will lock the chime volume at its current level.

Audio level adjustment (amplified models only):

- With the vehicle and radio turned on, turn the volume up 3/4 of the way.
- With a small screwdriver, adjust the potentiometer clockwise to raise the audio level; counterclockwise to lower the audio level.
- Once at a desired level, your audio level adjustment is complete.

OnStar level adjustment:

- Press the OnStar button to activate it.
- While OnStar is speaking, press the VOLUME UP or VOLUME DOWN buttons on the steering wheel to raise or lower the OnStar level.
- If the vehicle does not come equipped with steering wheel controls, find the **Black/Yellow** wire on the 22-pin harness.
- While OnStar is speaking, tap the **Black/Yellow** wire to ground. Once the OnStar level is set, it will stay at that level until the **Black/Yellow** wire is tapped to ground again.

EXTRA FEATURES

Factory rear seat entertainment and satellite radio control (in select vehicles):

- If your vehicle comes equipped with rear seat entertainment, or factory satellite radio, the GMOS-014 can retain these features.
- Change the source of the radio to AUX-IN; the satellite radio will start playing.
- The optional AX-LCD (sold separately) will now display your satellite radio information.
- Listed below are the functions of the AX-LCD buttons while using the satellite radio:
 - **Arrow up** - Channel up.
 - **Arrow down** - Channel down.
 - **Enter** - Selects current item on the screen.
 - **Return/ESC** - Exits to previous screen.
- To access the rear seat entertainment, press and hold the SOURCE button on the steering wheel for 2 seconds. Do this again to get back to the satellite radio.