

**Before returning this product  
to the store of purchase**

**Contact Dee Zee if you experience the following problems:**

- Missing Parts
- Installation Problems/Questions
- Warranty Questions



## Dee Zee Running Board Installation Instructions

*Congratulations on your purchase of a quality Dee Zee product. Dee Zee is recognized as having the highest quality running boards and accessories on the market today. We have earned this reputation by offering our customers a product they can be proud to place on their vehicles. Dee Zee meets all the criteria of manufacturing a custom-fit product which guarantees it to be the easiest product to install.*

**Note:** Please take time to read all of the instructions before beginning this installation.

**Warning!** Please check for wiring or other obstructions before drilling any holes into the vehicle. If it is necessary to drill any holes into the vehicle, Dee Zee recommends putting a sealant or rust inhibitor around all holes drilled into the body of the vehicle.

**Warning!** It is the sole responsibility of the vehicle owner to check for tire clearance.

















**Warning!** It is unlawful and dangerous to ride on running boards or side box boards while the vehicle is in motion.

**Cleaning Instructions:** To maintain the bright finish of your Dee Zee running boards, clean with a mild detergent. For our stainless steel products and accessories, the application of a high grade automotive type wax is recommended.

# Dee Zee FX Running Board Installation Instruction

(Clear) FX 11952 / (Black) FX 11352

(1999 - Current) Chevy Ext. Cab Pickup

<p><b>A</b> FX Running Board</p>  <p>BD 11938L/R - BD 1338L/R <b>X2</b></p>	<p><b>B</b> Bulb Seal Gasket</p>  <p><b>13.25 ft.</b></p>	<p><b>C</b> Mudflaps</p>  <p><b>1 Left Side</b> <b>1 Right Side</b></p>	<p><b>D</b> Endcaps</p>  <p><b>1 Left Side</b> <b>1 Right Side</b></p>
<p><b>E</b> Front Driver Side Body Mount Bracket</p>  <p><b>X1</b></p>	<p><b>F</b> Middle Driver Side Body Mount Bracket</p>  <p>This is the shortest in the kit <b>X1</b></p>	<p><b>G</b> Rear Driver Side Body Mount Bracket</p>  <p>This is the tallest in the kit <b>X1</b></p>	
<p><b>H</b> Front Passenger Side Body Mount Bracket</p>  <p><b>X1</b></p>	<p><b>I</b> Middle Passenger Side Body Mount Bracket</p>  <p>This is the shortest in the kit <b>X1</b></p>	<p><b>J</b> Rear Passenger Side Body Mount Bracket</p>  <p>This is the tallest in the kit <b>X1</b></p>	
<p><b>K</b> 1/4 x 3/4" Slotted Hex Head Bolt</p>  <p>PN 86A <b>X12</b></p>	<p><b>L</b> 1/4" Flat Washer</p>  <p>PN 72 <b>X12</b></p>	<p><b>M</b> 1/4" Hex Nut</p>  <p>PN 71 <b>X12</b></p>	<p><b>N</b> 1/4 x 1" Black Sheet Metal Screw</p>  <p>PN 97B <b>X2</b></p>
<p><b>O</b> #10 x 5/8" Black Phillips Head Screw</p>  <p>PN 140 <b>X8</b></p>	<p><b>P</b> 1/4 x 1" Black Phillips Round Head Screw</p>  <p>PN 80 <b>X4</b></p>	<p><b>1/8" Drillbit</b></p>	

**Tools Required:**


**Ratchet / Wrench**

**Sizes:**


**18mm**

**7/16"**

**3/8"**




**Tin-snips**




**Tape Measure**

**1/8" Drillbit**






**Drill**



**Phillips Head  
Screwdriver**

**1**


Place bulb-seal gasket (B) onto the backlip of fx running board (A) as shown below. Cut bulb-seal gasket (B) so that it is flush with the ends of fx running board (A).



**Tin-snips**


**2**

Place three 1/4 x 3/4" slotted hex head bolts (K) into each channel on the bottom of fx running board (A) as shown below.




**3**

Place fx endcap (D) onto the rear of fx running board (A) as shown below. Secure into place using 1/4 x 1" phillips round head screws (P). Tighten into place using a phillips head screwdriver.



**4**

Place fx mudflap (C) onto the front of fx running board (A) as shown below. Secure into place using a 1/4 x 1" sheet metal screw (N). Tighten into place using a 3/8" wrench / socket.






**5**

Locate and remove the front / middle / rear body mount bolts shown below using an 18mm socket/ratchet. Do not discard the body mount bolt or rubber bushing. They will be used in the next step of this installation.

**18mm Wrench  
or Socket**



**Front Body Mount**



**Middle Body Mount**




**Rear Body Mount**

**6**

**Front / Middle / Rear**

**Place the body mount bolt through the hole in the front body mount bracket and the rubber bushing. Place this assembly up to the body mount locations and loosely hand tighten into place. See below.**

**18mm Wrench  
or Socket**



**Front Body Mount**



**Middle Body Mount**  
(Looking towards the front of the truck)




**Rear Body Mount**  
(Looking towards the front of the truck)



7

7/16" Wrench  
or Socket





Place the 1/4 x 3/4" Slotted Hex Head Bolts (K) in the slots on the bottom of the board (3 bolts per slot). Place the Running Board on the front / middle / rear Body Mount Brackets. Align the 1/4 x 3/4" Hex Head Bolts with the slots in the Body Mount Brackets. Secure into place using 1/4" flat washer (L) and 1/4" hex nuts (M). Make any final adjustments to the alignment of the running board on the vehicle and then tighten the Body Mount Bolts, then align board and tighten board bolts.






# 8


Using the pictures below as a guide, first drill three 1/8" holes through the mudflap on the running board and the sheet metal in the wheel well opening of the vehicle. Secure the mudflap to the sheetmetal of the wheel well opening using #10 x 5/8" phillips head screws (O) as shown in Step 9 of this instruction. Tighten until snug using a phillips head screwdriver. Now drill a 1/8" hole through the bottom of the mudflap and the fx running board as shown below. Secure the mudflap to the bottom of the fx running board using #10 x 5/8" phillips head screws (O) as shown in Step 9 of this instruction.




Drill through mudflap and wheel well opening.



Drill through bottom of mudflap and bottom of running board.





Secure mudflap to wheel well opening using #10 x 5/8" phillips head screws (O).

Secure mudflap to wheel well opening using a #10 x 5/8" phillips head screw (O).

