



## GT9 Installation Hub Models #10-5506 & #20-5506

### Parts List:

- Hub (1)
- Column wire (1)
- Ground wire (1)
- Ground wire screw (1)
- Wheel screws (9)
- Allen wrench (1)



### FITMENT:

|                |                       |                                                                                                                 |
|----------------|-----------------------|-----------------------------------------------------------------------------------------------------------------|
| GM Autos       | 1969-93               | Chevrolet, Buick, Oldsmobile, Pontiac All Models (except Corvette, Sprint Spectrum, Nova 86-88, 1988-on Lemans) |
| GM Trucks      | 1974-94               | Chevrolet/GMC Truck & SUV All Models (including 1968-88 El Camino)                                              |
| JEEP           | 1976-95<br>1974-75    | All Models<br>Cherokee, Wagoneer, Pick-up                                                                       |
| Custom Columns | IDIDIT All GM Columns |                                                                                                                 |

### NOTICE

**Airbag equipped vehicles:** GT Performance Products steering wheels and hubs are **not** designed for use on Airbag equipped vehicles. **Due to Safety and Legal reasons**, we do not recommend changing, altering or removing the airbag from any vehicle.

### PRE-INSTALLATION INSTRUCTIONS

- Read all instructions completely prior to installation process!**
- Align wheels on vehicle straight ahead and disconnect battery.
- Removal of Original or Custom Steering Wheel:** Refer to shop manual for your vehicle or manufacturer of custom steering wheel. **Note:** A steering wheel or gear puller may be required.

### INSTALLATION INSTRUCTIONS

- Once original wheel is removed from column, remove wire from steering column and replace with column wire supplied. (Push down and twist counter-clockwise to remove and reverse to install new column wire).
- Install ground wire to hub as shown in photo A.
- Note **“top”** marking on hub (2 vertical dimples next to one of the (9) nine holes which indicates **“top”**). Position hub onto shaft, carefully routing wire thru hub as shown in photo A.

Photo A



- Install shaft nut and tighten.

### TORQUE REQUIREMENTS

Shaft nut: 25 / 30 ft. lbs.

- Install wheel onto hub and tighten the (9) wheel screws. **CAUTION:** Do not over tighten mounting screws; this will cause damage to the hub.
- Connect wires to bottom of horn button and carefully push horn button into hub flange. (Photo B) **Note:** If necessary, slightly wet the O-ring to ease installation.

Photo B



- Reconnect battery and test operation of horn and turn signal canceling.

**NOTE:** **TO REMOVE HORN BUTTON:** Insert small, non-marring plastic blade, or screw driver between notch on bottom of horn button and wheel surface and carefully pry to release.