


Important:

Please read these instructions carefully prior to installation. Please refer to your fitting instruction to ensure that the bike rack is installed in the correct locations.

Check the contents of kit before commencing fitment and report any discrepancies.

Place these instructions in the vehicle's glove box after installation is complete.



Important Information

Maximum carrying capacity: 15kg (33lbs) per bike. Max 4 Bikes. Totalling 60kg/ 130lbs.

Warning: Do not attempt to fit the bike carrier to your vehicle unless you fully understand this fitting instructions. Please direct any questions regarding fitting to the dealer from where the bike carrier was purchased. Use only non-stretch fastening ropes or straps.

Recommendations:

It is essential that all bolt connections be checked after driving a short distance when you first install your bike carrier. Bolt connections should be checked again at regular intervals (once a week is enough, depending on road conditions, usage, loads and distances travelled). You should also check the bike carrier each time it is re-fitted. Always make sure to fasten your load securely. Please also ensure that all loads are evenly distributed and that the centre of gravity is kept as low as possible. Bike carrier must be removed when putting vehicle through an automatic car wash.

In some states it may be against the law to obstruct clear view of lamps and registration plates. It is suggested that the Rhino-Rack Number Plate Holder (RBCA011) be purchased.

Caution: The handling characteristics of the vehicle changes when you transport a load on the roof or at the rear. For safety reasons we recommend you exercise extreme care when transporting wind-resistant loads. Special consideration must be taken into account when cornering and braking.


Note for Dealers and Fitters




General Parts List


Item	Component Name	Qty	Part No.
1	Support Arm	1	-
2	Mast	1	-
3	Receiving Bar	1	-
4	Multi Facted Bike Holders	4	-
5	Rubber Straps	12	-
6	Lever	1	-
7	Instructions	1	R1181


Tools Required: 1: Socket Wrench 2: Allen Key







Instructions


































Using the Rubber Straps on the Carrier, Fix the rear of the Frame in place.




Loop a Strap over the top of the Frame and secure in place.





Using the Rubber Straps on the Carrier, Fix the front of the Frame in place.






Fix the bikes in place using the Strap provided. Wrap the Strap through both wheels of the bike and around the Back of the Bike Carrier.
















Top View: For additional Bikes (4 max), face Bike in alternate directions. This will ensure the Bikes will not clash together during travel. Ensure there is no obstruction of view to lamps and registration plates, adjust fork positions to achieve this if required.



14 To access the rear of the vehicle, remove the Security Pin. Lift up the Lever as shown. The Rack will tilt forward. This is only to be done when bikes are not on the Rack.





Note: Check the Bikes do not cover/ block the Tail Lights and Licence Plate. An RBCA011 (License Plate Holder) may be required to meet road and safety regulations in your state.