



OVER 35 YEARS OF INNOVATION, QUALITY, SAFETY.

A faint, light-colored image of a tie-down strap is visible in the background, behind the main text. The strap has a metal hook on one end and a ratchet handle on the other.

**TRUE FRAME MOUNTED
CAMPER TIE DOWNS**

IMPORTANT OWNER-OPERATOR INSTALLATION INSTRUCTIONS

D2101/D2115/D2118

Warnings

Truck Bed and Camper Protection

Torklift **does not** recommend installing your camper on top of a plastic bed liner (or other compressible material such as foam). These materials can act as a spring, causing increased vertical truck camper movement independent of the vehicle. Plastic bed liners can slide on the truck bed surface, and the truck camper can slide on top of the bed liner. Using a plastic bed liner or similar compressible material will void your warranty and may additionally cause truck bed and/or camper damage.

Minor movement or settling can occur in some incidental harsh driving conditions (on or off-road). A rubber bed mat is recommended to protect the truck bed and camper, but is not a requirement to maintain the Torklift legendary lifetime warranty.

Suspension

To significantly reduce body roll, sag and sway Torklift strongly recommends the StableLoad. Torklift International StableLoads improve safety, handling, and to help level your truck.

If your truck is additionally equipped with suspension air bags Torklift cautions against over pressurization as this may lead to unsafe vehicle handling characteristics. We have found that airbags used in conjunction with StableLoads have allowed operators to lower air bag pressure by 50% or more. Only pressurize suspension air bags enough to level the truck.

NOTE:

If your vehicle is equipped with a factory fuel tank skid plate, which is included with the “Off Road Group” or “Protection Group” packages, it will be necessary to drill the skid plate bracket in order to mount the tie downs. This is only necessary if your skid plate attaches to the outboard portion of the truck frame covering the forward factory frame holes. To do this, remove the two factory bolts holding the skid plate bracket to the side of the frame. Note the location of the factory hole behind the skid plate bracket and mark the skid plate bracket accordingly. Drill the skid bracket out to 17/32” with a drill bit and install the two factory bolts in the skid plate. The factory hole in the frame will now be accessible. Place a 1” x 2” plate washer to be used as a shim on to each of the newly installed tie down bolts further on in the installation. The shims will move the tie down frame plate out slightly to clear the skid plate-mounting bracket. Photos are on following page.

You may now continue on to the installation instructions on page 3.


D2101/D2115/D2118 PARTS INVENTORY

- 2 - [Tie Down Receivers](#)
- 4 - 1/2" Nuts
- 2 - Bent Tie Down Inserts
- 2 - 1/4" Pins
- 4 - 1/2" X 2" Hex Bolts
- 4 - 1"(2.54cm) X 2"(5.08cm) Plate Washers - Designed For Skid Plate
- 2 - 1"(2.54cm) X 3"(7.62cm) Plate Washers
- 6 - 1/2" Star Washers
- 10 - 1/2" Flat Washers
- 1 - 1/2" Bolt Fisher
- 4 - 1/2" Lock Washers
- 2 - 5"(12.7cm) X 3-1/4"(8.25cm) Spacer Plates

D2118 ONLY-

- 2 - 3/8" Lower Frame Bracket
- 2 - 1/2"-13 x 3-1/2" Hex Bolt Grade 8

Driver's side view of the Cab mount and bed mount area. This is going to be the area the tie down will install. Notice the two holes in the side of the frame and the bolt for the bed cross member.



INSTALLATION INSTRUCTIONS:


Step 1-

Locate and inventory all parts and become familiar with all brackets. Chock the vehicle tires and set Emergency Brake before attempting any part of this install.

Step 2-

Remove the factory upper bed bolt (Photo 2.1)


Photo 2.1



Step 3-

Find the driver's side tie down receiver. Hold the tie down in place against the vehicle bed cross member and align with the factory hole. Locate a 5" (12.7cm) X 3-1/4" (8.25cm) spacer plate. This will be sandwiched between the tie down strap and the bed cross member. **(Photo 3.1)**

Photo 3.1



Note: *The spacer plate will have a hole that is offset which should face the rear of the vehicle.*

Step 4-

Re-install factory bolt (bolt removed in **Step 2**) through the tie down strap and 5" (12.7cm) X 3-1/4" (8.25cm) SPACER PLATE. Hand tighten.

Step 5-

Now hold the tie down receiver bracket against the side of the vehicle frame at the front of the truck box, until the factory hole on the side of the vehicle frame line up with the hole in the rear of the tie down receiver.

Step 6- For 2003-2012 truck models proceed to (A); for 2013 truck models proceed to (B)

A: Locate the smaller of the two holes on the side of the truck's frame toward the front of the vehicle. Fish 1/2" X 2" hex bolt with a 1/2" star washer and a 1/2" flat washer followed by another 1/2" star washer through the larger hole in the vehicles frame into the tie down receiver (**See our bolt fishing guide**). Proceed to (B)


B: Locate the hole on the tie down receiver toward the rear of the vehicle. Place the 1/2" X 2" hex bolt with a 1/2" star washer followed by a 1"(2.54cm) X 3"(7.62cm) plate washer through the large hole in the vehicle frame. Now pull assembly out of the same hole you placed it into using the bolt fisher. Bring the bolt through into the tie down receiver. (**Photo 6.1**)

Photo 6.1



Step 7- 2013 truck models only-

On the inside and below the Cab Mount on the frame, take the 3/8" Lower Frame Bracket and attach it on the inside of the frame. There is a pocket on the lower inside of the frame that the 3/8" Lower Frame Bracket will slide up and into. Place one 1/2"-13 x 3-1/2" Hex Bolt Grade 8 through the 3/8" Lower Bracket and through the Tie Down. Then place two 1/2" flat washers, a 1/2" lock washer, and a 1/2" nut onto both front and rear receiver bolts and firmly tighten the receiver to the vehicle frame. This will be tightened to 80 ft-lbs(108 Nm).



Step 7-

Tighten the tie down receiver with the factory bed bolt 80 ft-lbs. to bed cross member.

Step 8- 2003-2012 Truck models only.

Now place two 1/2" flat washers, a 1/2" lock washer, and a 1/2" nut onto both front and rear receiver bolts and firmly tighten the receiver to the vehicle frame. This will be tightened to 80 ft-lbs (108 Nm).

Step 9-

Find one bent tie down insert and 1/4" pin and put the tie down insert into the receiver using the hole in the insert. Install 1/4" pin. Double-check that all bolts are tight and that there is 1" of clearance on the insert and truck box lip. Repeat all steps on driver's side.

Completed Install



PROPER BOLT ASSEMBLY

FIGURE A



FIGURE B



The star washers have been supplied to keep the bolt from spinning while tightening the nut to proper specifications.

Again, the star washers are only required on fastener applications where the head of the bolt CAN NOT be accessed (inside a boxed frame etc.) with a wrench to hold the bolt from spinning while tightening the nut by hand.

Note: The upper row as shown in the photo including the hex bolt, star washers, and flat washer is the assembly from the inside of the vehicle frame, the lower row which includes the flat washer, lock washer, and nut will be used to tighten the assembly from the outside of the frame.

INSTRUCTIONS FOR MAINTENANCE OF POLISHED STAINLESS STEEL PRODUCTS




Torklift utilizes quality grade 304 stainless steel in this product.

304 stainless steel is well known for its anti corrosive properties, however in some environments such as coastal regions or when in contact with some road chemicals, corrosion may occur.


We recommend occasional polishing of our product to maintain its attractive finish. Use an approved stainless steel cleaning/polishing product, which can be purchased from any automotive supplier.

TORKLIFT'S BOLT FISHING GUIDE

Your guide to understanding the installation of our frame mounted tie downs.




Note: The hardware may vary as to what is being fished along with the bolt. In this instance a 1" X 2" plate washer is being fished along with the hex bolt. Different applications may require fishing through various star washers and flat washers for example.



Desired Hole on Vehicle (Place the coiled end of the bolt fisher through this hole).

This side of the Bolt Fisher should come out of a hole where the required hardware (for example 1" X 2" plate washer) can pass through.



This bottom example shows the bolt when it's completely fished through the vehicle. You may find it easier to keep the bolt fisher attached until you get the tie down receiver in place so that the bolt doesn't fall into the vehicle frame.

WARNING: PULLING TOO HARD ON THE BOLT FISHER CAN RESULT IN LOST FASTENERS, OR BROKEN BOLT FISHER.

TIEDOWN INSERT INSTALLATION INSTRUCTIONS

On one end of each of your tie down inserts is a triangular plate referred to by Torklift as a bullet plate. Your tie down inserts should be installed with the shorter side of the bullet plate facing away from each other, i.e.. The shorter side of the front insert should point to the front of the truck and the shorter side of the rear insert should point towards the rear of the truck.

Once installed, attach the TorkLift directional stickers to the face of the bullet plate on the insert as a reminder.

DRIVERS SIDE FRONT

DRIVERS SIDE REAR



IMPORTANT NOTE: *Your tie down inserts are designed to have clearance inside of the receiver. This is to account for road debris, as well as aid in installation and removal. Some rattle may be expected if the inserts are left installed while not under load from the camper.*

RECOMMENDED TRUCK CAMPER

INSTALLATION INSTRUCTIONS

When securing any heavy load (especially a camper) in your truck bed, your front tie down points should pull the load forward as much as possible. Some camper anchor points may differ with different manufacturers, as well as the camper jack mounting locations. Your Torklift tie down inserts has offset triangular brackets to increase the angle of pull. These are designed to be used in the front facing forward, and the rear facing rearward but can be used in either front or rear. These recommendations are to be considered and followed as a basic rule of thumb. Obviously there will be some applications where this may not be possible. At a minimum, if opposite pull of both front and rear tie downs cannot be achieved for whatever reason, you should have at least a forward pull at the front or rear location.

If your camper does not come with Rubber Bumpers on the front lower portion of the camper, installing Rubber Bumpers (Torklift has Rubber Bumpers available Part A7001) or using a block of wood such as a 2 x 4 in the bed, will prevent the camper from damaging the front bulk head of the truck bed.

Minor movement (or settling) can occur in some incidental harsh driving conditions (on or off road). A rubber bed mat is not a requirement to maintain the lifetime warranty on a Torklift system, but a strong recommendation simply as a safety precaution to protect the truck bed, the bottom of the camper and to give the camper additional support.

TORKLIFT DOES NOT RECOMMEND: Installing your truck camper in your truck on top of a drop in plastic bed liner!!! The drop in plastic bed liners can slide on top of the truck bed surface, and the camper can slide on top of the slick surface of the bed liner. The liner can also act as a spring causing a trampoline effect increasing vertical truck camper movement, independent of the vehicle, possibly resulting in truck bed, and camper damage!

INSTRUCTIONS FOR FINISH MAINTENANCE

OF TORKLIFT PRODUCTS

POWDER COATED STEEL:

To keep your Torklift products looking good follow these guidelines. All steel powder coated Torklift products are sandblasted for maximum adhesion and use a high quality industrial urethane based powder coat. Due to the extreme, harsh, undercar environment that your Torklift products live in, (consistently sprayed with corrosive road chemicals such as salt, and road debris), Torklift does not warranty the power coated finish.

To minimize corrosion from these factors on powder coated steel products, Torklift recommends regularly cleaning and inspecting the powder-coated surface and touching up any affected areas with enamel or urethane based aerosol paint product. If there are any areas of surface rust, there are also aerosol spray rust converters available on the market that can be used as a preparation to touch-up paint application. These finish maintenance products are available at any automotive parts supplier.

POLISHED STAINLESS STEEL:

Torklift utilizes quality grade 304 stainless steel in our stainless steel polished products. 304 stainless steel is well known for its anti-corrosive properties. However, in some environments such as coastal regions or when coming in contact with some road chemicals, corrosion may occur.

For a quick clean simply use WD40 and a cloth rag. We also recommend occasional polishing of our polished stainless products to maintain their attractive finish. Use an approved stainless steel chrome or aluminum mag wheel polish cleaning product, which can be purchased from any automotive parts supplier.



TRUE FRAME MOUNTED CAMPER TIE DOWNS

IMPORTANT OWNER-OPERATOR INSTALLATION INSTRUCTIONS

D2101/D2115/D2118-FMTPJ13DGHD

FRONT TIE DOWNS

Minor movement (or settling) can occur in some incidental harsh driving conditions
(On or off road).

A rubber bed mat is not a requirement to maintain the lifetime warranty on a Torklift system, but a strong recommendation, simply as a safety precaution to protect the truck bed, the bottom of the camper and to give the camper additional support.

Warning!!

TORKLIFT DOES NOT RECOMMEND: Installing your truck camper in your truck on top of a drop in plastic bed liner!!! THIS WILL VOID YOUR WARRANTY!

The drop in plastic bed liners can slide on top of the truck bed surface, and the camper can slide on top of the slick surface of the bed liner. The liner can also act as a spring causing a trampoline effect increasing vertical truck camper movement, independent of the vehicle, possibly resulting in truck bed damage and/or camper damage!

NOTE:

If your vehicle is equipped with a factory fuel tank skid plate which is included with the “Off Road Group” or “Protection Group” packages, it will be necessary to drill the skid plate bracket in order to mount the tie downs. This is only necessary if your skid plate attaches to the outboard portion of the truck frame covering the forward factory frame holes. To do this, remove the two factory bolts holding the skid plate bracket to the side of the frame. Note the location of the factory hole behind the skid plate bracket and mark the skid plate bracket accordingly. Drill the skid bracket out to 17/32” with a drill bit and install the two factory bolts in the skid plate. The factory hole in the frame will now be accessible. Place a 1” x 2” plate washer to be used as a shim on to each of the newly installed tie down bolts further on in the installation. The shims will move the tie down frame plate out slightly to clear the skid plate mounting bracket. Photos are on following page.

You may now continue on to the installation instructions on page 3.


D2101/D2115/D2118 PARTS INVENTORY

- 2 -Tie Down Receivers
- 4 -1/2" Nuts
- 2 -Bent Tie Down Inserts
- 2 -1/4" Pins
- 4 -1/2" X 2" Hex Bolts
- 4 -1" X 2" Plate Washers - Designed For Skid Plate
- 2 -1" X 3" Plate Washers
- 6 -1/2" Star Washers
- 10 -1/2" Flat Washers
- 1 -1/2" Bolt Fisher
- 4 -1/2" Lock Washers
- 2 -5" X 3-1/4" Spacer Plates

D2118 ONLY-

- 2 -3/8" Lower Frame Bracket
- 2 -1/2"-13 x 3-1/2" Hex Bolt Grade 8

Drivers side view of the Cab mount and bed mount area. This is going to be the area the tie down will install. Notice the two holes in the side of the frame and the bolt for the bed cross member.



INSTALLATION INSTRUCTIONS:


Step 1-

Locate and inventory all parts and become familiar with all brackets. Chock the vehicle tires and set Emergency Brake before attempting any part of this install.

Step 2-

Remove the factory upper bed bolt (**Photo 2.1**)


Photo 2.1



Step 3-

Find the drivers side tie down receiver. Hold the tie down in place against the vehicle bed cross member and align with the factory hole. Locate a 5" X 3-1/4" spacer plate. This will be sandwiched between the tie down strap and the bed cross member. (Photo 3.1)

Photo 3.1



Note: *The spacer plate will have a hole that is offset which should face the rear of the vehicle.*

Step 4-

Re-install factory bolt (bolt removed in **Step 2**) through the tie down strap and 5" X 3-1/4" SPACER PLATE. Hand tighten.

Step 5-

Now hold the tie down receiver bracket against the side of the vehicle frame at the front of the truck box, until the factory hole on the side of the vehicle frame line up with the hole in the rear of the tie down receiver.

Step 6- For 2003-2012 truck models proceed to (A); For 2013 truck models proceed to (B)

A: Locate the smaller of the two holes on the side of the truck's frame toward the front of the vehicle. Fish 1/2" X 2" hex bolt with a 1/2" star washer and a 1/2" flat washer followed by another 1/2" star washer through the larger hole in the vehicles frame into the tie down receiver (**See our bolt fishing guide**). Proceed to (B)

B: Locate the hole on the tie down receiver toward the rear of the vehicle. Place the 1/2" X 2" hex bolt with a 1/2" star washer followed by a 1" X 3" plate washer through the large hole in the vehicle frame. Now pull assembly out of the same hole you placed it into using the bolt fisher. Bring the bolt through into the tie down receiver. (**Photo 6.1**)

Photo 6.1



Step 7- 2013 truck models only-

On the inside and below the Cab Mount on the frame, take the 3/8" Lower Frame Bracket and attach it on the inside of the frame. There is a pocket on the lower inside of the frame that the 3/8" Lower Frame Bracket will slide up and into. Place one 1/2"-13 x 3-1/2" Hex Bolt Grade 8 through the 3/8" Lower Bracket and through the Tie Down. Then place two 1/2" flat washers, a 1/2" lock washer, and a 1/2" nut onto both front and rear receiver bolts and firmly tighten the receiver to the vehicle frame. This will be tightened to 80 ft-lbs.


INSIDE OF THE BED

FUEL TANK

3/8" LOWER FRAME BRACKET

TIE DOWN

1/2"-13 X 3-1/2" HEX BOLT GRADE 8



Step 7-

Tighten the tie down receiver with the factory bed bolt 80 ft-lbs. to bed cross member.

Step 8- 2003-2012 Truck models only.

Now place two 1/2" flat washers, a 1/2" lock washer, and a 1/2" nut onto both front and rear receiver bolts and firmly tighten the receiver to the vehicle frame. This will be tightened to 80 ft-lbs.

Step 9-

Find one bent tie down insert and 1/4" pin and put the tie down insert into the receiver using the hole in the insert. Install 1/4" pin. Double-check that all bolts are tight and that there is 1" of clearance on the insert and truck box lip. Repeat all steps on driver's side.

Completed Install



PROPER BOLT ASSEMBLY

FIGURE A



FIGURE B




The star washers have been supplied to keep the bolt from spinning while tightening the nut to proper specifications.

Again, the star washers are only required on fastener applications where the head of the bolt CAN NOT be accessed (inside a boxed frame etc) with a wrench to hold the bolt from spinning while tightening the nut by hand.

Note: The upper row as shown in the photo including the hex bolt, star washers, and flat washer is the assembly from the inside of the vehicle frame, the lower row which includes the flat washer, lock washer, and nut will be used to tighten the assembly from the outside of the frame.

ATTENTION - PLEASE NOTE!!!



**The notch in the plate,
denotes which end of the plate needs
to go toward the rear of the truck.**

Plate Design May Vary

**In an attempt to make the installation of our tie downs
easier, we have cut a small triangular notch on the edge of
our frame plates.**

**NOTE: THE DIAGRAM ABOVE DOES NOT REPRESENT
ANY ACTUAL TORKLIFT TIE DOWN FRAME PLATE.**

INSTRUCTIONS FOR MAINTENANCE OF POLISHED STAINLESS STEEL PRODUCTS




TorkLift utilizes quality grade 304 stainless steel in this product.

304 stainless steel is well known for its anti corrosive properties, however in some environments such as coastal regions or when in contact with some road chemicals, corrosion may occur.

We recommend occasional polishing of our product to maintain its attractive finish. Use an approved stainless steel cleaning/polishing product which can be purchased from any automotive supplier.

Frame Mounted Tie Downs

Leading the camper tie down industry in strength, quality, advanced design and installation. TorkLift TRUE frame mounted tie downs are far superior to all tie down systems available.



The TorkLift system is unique in its design and is patented. Four independent tie down points (with no belly or crossbar) working much like your receiver type trailer hitch as the inserts are removable allowing the system to be virtually undetectable when not in use.

They are designed for each make and model to fit tight to the frame so as not to compromise ground clearance. TorkLift tie downs are not universal 'one size fits all' therefore all the problems with correct fit for each particular application have been eliminated.

Original SuperHitch & SuperHitch Magnum


High strength extended hitch system engineered for safely towing all types of trailers behind your truck and camper. With a max towing capacity of 14,000 lbs. with an extension* , (17,000 lbs. to 20,000 lbs. without*) the Original SuperHitch and SuperHitch Magnum are rated the strongest in the industry.



TORKLIFT'S BOLT FISHING GUIDE

Your guide to understanding the installation of our frame mounted tie downs.

-Coiled End of Bolt Fisher-




Note: The hardware may vary as to what is being fished along with the bolt. In this instance a 1" X 2" plate washer is being fished along with the hex bolt. Different applications may require fishing through various star washers and flat washers for example.

Desired Hole on Vehicle (Place the coiled end of the bolt fisher through this hole).

This side of the Bolt Fisher should come out of a hole where the required hardware (for example 1" X 2" plate washer) can pass through.

-Opposite End of Bolt Fisher-



This bottom example shows the bolt when it's completely fished through the vehicle. You may find it easier to keep the bolt fisher attached until you get the tie down receiver in place so that the bolt doesn't fall into the vehicle frame.


WARNING: PULLING TOO HARD ON THE BOLT FISHER CAN RESULT IN LOST FASTENERS, OR BROKEN BOLT FISHER.

TIE DOWN INSERT INSTALLATION INSTRUCTIONS

On one end of each of your tiedown inserts is a triangular plate referred to by TorkLift as a bullet plate. Your tiedown inserts should be installed with the shorter side of the bullet plate facing away from each other, i.e.. The shorter side of the front insert should point to the front of the truck and the shorter side of the rear insert should point towards the rear of the truck.

Once installed, attach the TorkLift directional stickers to the face of the bullet plate on the insert as a reminder.

DRIVERS SIDE FRONT



DRIVERS SIDE REAR



SHORTER SIDE

TURNBUCKLE SPRINGLOAD OPTIONS

CONTACT YOUR LOCAL DEALER FOR MORE DETAILS

TorkLift requires all 4 tiedown points to be spring loaded in order to qualify for our manufacturer's

Industry Exclusive "Camper Anchor" and "Truck Frame" Warranty

BASIC SPRINGLOAD KIT - S9000

Includes 2 External Springload Cylinder Units,
2 Heavy Duty Forged Turnbuckles and 24" of Chain.
Also comes with the TorkLift Lifetime Guarantee.



FASTGUNS LEVER ACTION TURNBUCKLES

FOR BED MOUNTED TIEDOWNS

S9520-GREY SS / S9521-WHITE SS / S9527-POLISHED SS

FOR FRAME MOUNTED TIE DOWNS

S9522-GREY SS/ S9523-WHITE SS/ S9526-POLISHED SS

S9529-BLACK SS

FRAME OR BUMPER MOUNTED TIEDOWNS

Includes 2 Stainless Steel Turnbuckles with an Internal
"Set" Spring. Available in 2 Lengths and 4 Finishes
(Grey, White, Polished Stainless Steel and Black)

Also comes with the TorkLift Lifetime Guarantee.

FASTGUN DERRINGERS Polished Stainless S9528

Transforms Your Pre-Existing Conventional
Turnbuckles into a Lever Action
FastGun Style Turnbuckle.

Kit includes 4 Lever Action Derringers.

Also comes with the TorkLift Lifetime Guarantee.



SPRINGLOAD XL KIT - S9050A

This set includes 2 Long Square Bodied
Turnbuckles with an Internal "Set" Spring.

The Springload XL Kit comes with a High Impact Powder-coated Finish and is compatible with the FastGun Derringer handles. Also comes with the TorkLift Lifetime Guarantee.



RECOMMENDED TRUCK CAMPER

INSTALLATION INSTRUCTIONS

When securing any heavy load (especially a camper) in your truck bed, your front tie down points should pull the load forward as much as possible. Some camper anchor points may differ with different manufacturers, as well as the camper jack mounting locations. Your TorkLift tie down inserts have offset triangular brackets to increase the angle of pull. These are designed to be used in the front facing forward, and the rear facing rearward but can be used in either front or rear. These recommendations are to be considered and followed as a basic rule of thumb . Obviously there will be some applications where this may not be possible. At a minimum, if opposite pull of both front and rear tiedowns cannot be achieved for whatever reason, you should have at least a forward pull at the front or rear location.

If your camper does not come with Rubber Bumpers on the front lower portion of the camper, installing Rubber Bumpers (TorkLift has Rubber Bumpers available Part A7001) or using a block of wood such as a 2 x 4 in the bed, will prevent the camper from damaging the front bulk head of the truck bed.

Minor movement (or settling) can occur in some incidental harsh driving conditions (on or off road). A rubber bed mat is not a requirement to maintain the lifetime warranty on a TorkLift system, but a strong recommendation simply as a safety precaution to protect the truck bed, the bottom of the camper and to give the camper additional support.

TORKLIFT DOES NOT RECOMMEND: Installing your truck camper in your truck on top of a drop in plastic bed liner!!! The drop in plastic bed liners can slide on top of the truck bed surface, and the camper can slide on top of the slick surface of the bed liner. The liner can also act as a spring causing a trampoline effect increasing vertical truck camper movement, independent of the vehicle, possibly resulting in truck bed, and camper damage!

INSTRUCTIONS FOR FINISH MAINTENANCE **OF TORKLIFT PRODUCTS**

POWDER COATED STEEL:

To keep your TorkLift products looking good follow these guidelines. All steel powder coated TorkLift products are sandblasted for maximum adhesion and use a high quality industrial urethane based powder coat. Due to the extreme, harsh, undercar environment that your TorkLift products live in, (consistently sprayed with corrosive road chemicals such as salt, and road debris), TorkLift does not warranty the powder coated finish.

To minimize corrosion from these factors on powder coated steel products, TorkLift recommends regularly cleaning and inspecting the powder coated surface and touching up any affected areas with an enamel or urethane based aerosol paint product. If there are any areas of surface rust, there are also aerosol spray rust converters available on the market that can be used as a preparation to touch-up paint application. These finish maintenance products are available at any automotive parts supplier.

POLISHED STAINLESS STEEL :

TorkLift utilizes quality grade 304 stainless steel in our stainless steel polished products. 304 stainless steel is well known for its anti-corrosive properties. However, in some environments such as coastal regions or when coming in contact with some road chemicals, corrosion may occur.

For a quick clean simply use WD40 and a cloth rag. We also recommend occasional polishing of our polished stainless products to maintain their attractive finish. Use an approved stainless steel chrome or aluminum mag wheel polish cleaning product which can be purchased from any automotive parts supplier.